

ASSEMBLY INSTRUCTIONS

Description: HIGHLAND ACCENT BENCH

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Seat Frame		1
P2	Shelf Frame		1
P3	Side Legs		4
P4	Center Legs		2

Hardware List


Item	Description	QTY	
H1	Bolts 1/4" x 2 1/2"	<u> </u>	12
H2	Bolts 1/4" x 1 3/8"	<u> </u>	6
НЗ	Lock Washers 1/4"	0	18
H4	Flat Washers 1/4"	0	18
H5	Allen Wrench	<u></u>	1

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:

Step 1: Assemble the Bench on the Flat, Soft surface as a carpet or cloth to prevent scratching the finish. Attach the Side Legs (P3) and Center Legs (P4) to the Seat Frame (P1) as shown below, do not tighten Bolts: (H1)x8 (H2)x4 Bolts 1/4" x 1 3/8" @ (H3)x12 Lock Washers 1/4" <u></u> **H4**) (H4)x12 Flat Washers 1/4" (P3) (H5)x1 Allen Wrench **H3 x2** (P4) (H1) (H5) O (H3) (H2) (H5)



Step 3: Turn the assembled Bench to an upright position. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase