
 <b>海宫</b> hai gong	产品名称	材质	颜色	尺寸	页数	修改日期	备注
	说明书		单色	142.5x210mm	8P	2025年8月8日15:32:14	



**Electric Fireplace**  
Portable

Model: TPL-ES-C

**OWNER'S MANUAL**

AC 120V 60Hz 1500W

**SAFETY INSTRUCTIONS FOR BATTERY**

READ AND SAVE THESE INSTRUCTIONS

1. Before and immediately remove or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
2. This used battery may cause severe injury or death.
3. Call a local poison control center for treatment information.
4. ONLY use the sea battery of CR2032 type.
5. Only use the CR2032 type battery.
6. Sea-rechargeable batteries are not to be recharged.
7. Do NOT force disassembly, overcharge, disassemble, heat above manufacturer's specified temperature method or incineration. Doing so may result in injury due to burning, leakage or explosion resulting in chemical burns.
8. Remove the batteries are installed correctly according to polarity (+ and -).
9. Do not mix old and sea batteries. Different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
10. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
11. Always regularly remove the battery compartment. If the battery compartment does not close correctly, stop using the product, remove the battery, and keep them away from children.

**WARNING**

- **POISON HAZARD:** This product contains a button cell or coin battery.
- **DEATH or serious injury can occur if ingested.**
- **A swallowed button cell or coin battery can cause internal chemical burns in as little as 2 hours.**
- **KEEP fire and sea batteries OUT OF REACH OF CHILDREN.**
- **Seek immediate medical attention if a battery is suspected to be swallowed or ingested. Do not induce vomiting.**



Retain this manual for future use.

**Important Safety Instructions**

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.
2. **USE THIS HEATER ONLY AS DESCRIBED IN THIS MANUAL.** Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
3. **CAUTION!** This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet from the front of the heater and keep them away from the sides and rear.
4. **EXTREME CAUTION** is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
5. **ALWAYS** unplug heater when not in use.
6. **DO NOT** operate any heater if any of the following conditions are true:
  - a. Heater has a damaged cord or plug.
  - b. Heater has malfunctions.
  - c. Heater has been dropped or damaged in any manner.
 If any of the above are true, discontinue heater, or return to authorized service facility for examination and/or repair.
7. **DO NOT** use outdoors.
8. This heater is **NOT INTENDED** for use in bedrooms, laundry areas and similar indoor locations. **NEVER** locate heater where it may fall into a bathtub or other water container.
9. **DO NOT** run cord under carpeting. **DO NOT** cover cord with throw rugs, mats, or similar coverings. **DO NOT** route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
10. To disconnect heater, turn control to off, and then remove plug from outlet.
11. Connect to properly grounded outlets only.
12. **DO NOT** insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater.
13. To prevent a possible fire, **DO NOT** block air intakes or exhaust in any manner. **DO NOT** use on soft surfaces, like a bed, where openings may become blocked.
14. A heater has hot and arcing or sparking parts inside. **DO NOT** use in areas where gasoline, paint, or flammable liquids are used or stored.
15. **ALWAYS** plug heater directly into a wall outlet/ receptacle. **NEVER** use with an extension cord or reconfigurable power source (outlet power strip).
16. Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, lightheadedness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, turn off the heater and seek medical attention.
17. To avoid excessive room temperatures which can cause hyperthermia. **DO NOT** leave product running unattended in a confined space around infants or individuals with reduced physical, sensory, or mental capabilities.

**SAVE THESE INSTRUCTIONS FOR FUTURE USE.**

Subject: Thank You for Your Purchase!

Dear Customer,

Thank you for choosing our space heater! We truly appreciate your trust in our brand.

If you encounter any issues while using our product, please feel free to contact us via email. To help us assist you more efficiently, kindly provide the following details in your message:

Order Number,  
Detailed Description of the Issue,  
Relevant Photos or Screenshots (if applicable).


Our support team is committed to responding within 24 hours and will work diligently to resolve your concerns as quickly as possible.

Your satisfaction is our top priority, and we are always here to help.

Best regards,  
Customer Support Team  
E-mail: kettek2023@outlook.com

**Product Specifications**

Model	Power Source	Rated Power	Rated Voltage	Dimensions
TPL-ES-C	Electric Fireplace	1500-40Hz	1500W	242*140*204mm



- 1. Display panel
- 2. Glass panel
- 3.3D Flame
- 4. Belt
- 5. Air outlet
- 6. Air Inlet
- 7. Switch

**Usage Instructions**

**POSITION OF THE APPLIANCE**

The heater should only be operated at a minimum distance of 50 cm (19.34") from any wall or other object. Position the airflow in order to optimize the heating of the room. Avoid corners, small volume rooms, floors, and ceilings.

**OVER HEAT PROTECTION**

This heater is protected with an overheat protection function that switches off the appliance automatically in case of overheating (e.g., due to the total or partial obstruction of the airflow intake or/and exhaust). In the case of overheating, wait about 30 minutes for it to cool, and remove the object that is causing the obstruction. Then, switch heater back on as described above. The appliance should operate normally. Should the problem persist, please contact customer service or consult with a competent and qualified service technician.

**Care & Maintenance**

- Before cleaning the appliance, ensure it is disconnected from the power supply and has cooled down completely.
- To avoid the risk of electric shock, do not clean the heater with water and do not immerse it in water.
- The housing may be wiped with a slightly damp, soft-lint cloth.
- If necessary, dust particles accumulated in the air outlet openings may be removed with a vacuum cleaner.

**Important Safety Instructions**

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.
2. **USE THIS HEATER ONLY AS DESCRIBED IN THIS MANUAL.** Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
3. **CAUTION!** This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet from the front of the heater and keep them away from the sides and rear.
4. **EXTREME CAUTION** is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
5. **ALWAYS** unplug heater when not in use.
6. **DO NOT** operate any heater if any of the following conditions are true:
  - a. Heater has a damaged cord or plug.
  - b. Heater has malfunctions.
  - c. Heater has been dropped or damaged in any manner.
 If any of the above are true, discontinue heater, or return to authorized service facility for examination and/or repair.
7. **DO NOT** use outdoors.
8. This heater is **NOT INTENDED** for use in bedrooms, laundry areas and similar indoor locations. **NEVER** locate heater where it may fall into a bathtub or other water container.
9. **DO NOT** run cord under carpeting. **DO NOT** cover cord with throw rugs, mats, or similar coverings. **DO NOT** route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
10. To disconnect heater, turn control to off, and then remove plug from outlet.
11. Connect to properly grounded outlets only.
12. **DO NOT** insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater.
13. To prevent a possible fire, **DO NOT** block air intakes or exhaust in any manner. **DO NOT** use on soft surfaces, like a bed, where openings may become blocked.
14. A heater has hot and arcing or sparking parts inside. **DO NOT** use in areas where gasoline, paint, or flammable liquids are used or stored.
15. **ALWAYS** plug heater directly into a wall outlet/ receptacle. **NEVER** use with an extension cord or reconfigurable power source (outlet power strip).
16. Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, lightheadedness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, turn off the heater and seek medical attention.
17. To avoid excessive room temperatures which can cause hyperthermia. **DO NOT** leave product running unattended in a confined space around infants or individuals with reduced physical, sensory, or mental capabilities.

**SAVE THESE INSTRUCTIONS FOR FUTURE USE.**