




INSTRUCTION MANUAL

Laguna Poly Garden 48" Backless Bench
SKU: OP2001-BN

V.1.0

1. NOTICE

Do not overtighten screws. (Insert all screws before tighten screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Please secure all parts, screws and nuts before use.
- Recuprim that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in proximity of open flame or harmful/alkaline/acidic chemicals.
- Be aware that some parts are heavy and have sharp edges.

TOOLS REQUIRED

- Allen Wrench (provided)
- Wrench (provided)
- Wrench (provided)
- Wrench (provided)
- Wrench (provided)

HARDWARE

1. 1/4" x 1/2" BOLT 4 PCS	2. 1/4" x 1/2" BOLT 8 PCS	3. 1/4" x 1/2" BOLT 8 PCS	4. 1/4" x 1/2" BOLT 8 PCS	5. 1/4" x 1/2" BOLT 8 PCS
6. 1/4" x 1/2" BOLT 1 PC	7. 1/4" x 1/2" BOLT 1 PC			

PARTS

A. BENCH TOP 1 PC	B. BENCH LEG 4 PCS	C. BENCH RAIL 2 PCS
----------------------	-----------------------	------------------------

Page 1 of 4

PARTS

D. WOODEN CORNER
4 PCS

PRODUCT ASSEMBLY

1 Attach part C Bench Rail to 2 PCS of part B Bench Legs with 2 PCS of part 1 Bolt. Do the same to another Bench Rail and the other two Legs. Do not tighten bolts too much at this stage.

Page 2 of 4

2 Attach the combined legs (part B) to part A Bench Top with 4 PCS of part 2 Bolt, part 4 Wrench and part 5 Bolt.

3 Attach another combined legs (part B) to part A Bench Top with 4 PCS of part 2 Bolt, part 4 Wrench and part 5 Bolt.

Page 3 of 4

4 Attach 4 PCS of part D wooden corners to the combined legs (part B) and the rail of part A Bench Top with 8 PCS of part 3 Screws (provided).

5 Tighten all the bolts and nuts again for your secure usage. Thanks for purchasing this bench enjoy it.

Page 4 of 4