

**To avoid the risk of fire, explosion, or electric shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all electrical codes.**

**To avoid electric shock:**

Be certain electrical power is OFF before and during installation and maintenance.  
Luminaire must be connected to a wiring system with an equipment-grounding conductor.

**To avoid explosion:**

Make sure the supply voltage is the same as the rated luminaire voltage.  
Do not install where marked operating temperatures exceed the ignition temperature of the hazardous atmosphere.  
Do not operate in ambient temperatures above those indicated on the luminaire nameplate.

