










ITM.4527 #


Assembly Instruction

A	B	C	D	E	F	G	H
							
Chair base	Backrest	Remote control	Power cord	Remote control	Power source	Armpad	Connecting pole

STEP1




STEP2



Front
Plug it straight in at the front end of the jack

STEP3



Insert chair back to the chair base, make sure the slots on the back fully aligned to the bottom part


Assembly Instruction

STEP4

No.1 and No.2 wire connect with the backrest and chair base.
No.3 wire connects with backrest and power cord(D).
No.4 wire connects with backrest and remote control(E).
No.5 wire connect the motor and the wire from rightside armrest,
which use to connect the control panel.
No.6 wire connect the motor and power source (F).
NO.7 power cord for USB & Type-c

NOTE


- 1: Two same color wires connect.
- 2: Plug power cord and power source into outlet, then you can use all function.




2

Assembly Instruction

How to recline?




How to get footrest latch down and stand?




Assembly Instruction

How to use remote control?



Footrest bounced off function
Reclining function
Rise function
Backrest retraction function

How to use remote control?



POWER : Turn on/off remote control.
HEAT : Turn on/off heat function for lumbar part only.
INTENSITY : Control massage function from low to high.
MODE : Choose one massage mode you like(pulse, press,wave,auto, normal)
You can choose 1-4 massage parts(back, lumbar, thighs, legs)to enjoy.

How to use control panel that outside of right armrest?

Control panel is for chair lift and reclining function , also has dual USB outlets (5V2A+Type C) that keep your devices charging, such as nearly all smartphone(like iPhone, Samsung..), ipad, headphones, Kindle...

