



EBENCHICO

Allow Product to Expand



Let the sofa “expand” for **48 hours**.



Note: After unpacking, allow the sofa to rest undisturbed for at least 48 hours. For best results, wait up to 72 hours.

Reshaping Before Initial Use

- After 3 days, reshape the sofa by tapping and squeezing it.
- Firmly pat to help the filling expand and distribute evenly inside.



(Knock and Tap)



(Knock and Tap)



(Knock and Tap)



(Knock and Tap)



(Shake and Fluff)



(Squeeze and Knead)

IMPORTANT - READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

WARNING

Keep children away from the unpacking area to prevent the risk of suffocation from plastic bags or foam. This product is intended for adult use only, for domestic and indoor purposes.

Helpful Tip

After a month or longer of use, lightly tap the sofa to adjust its shape for a more comfortable seating experience.

Customer Support

If you have any questions or issues, please contact us at: support@ebenchico.com