


Assembly Instruction





MIX

Wood | Supporting
responsible forestry


FSC® C211622





N	X1	R	X3
			

G	X3	H	X6	
	 			
G-1	G-2	H-1	H-2	H-3
Ø4x20mm				

A	X12	B	X12
			
Ø6x35mm		Ø15x10mm	

J	X12
	
Ø2.5x12mm	

C	X8
	
Ø6x30mm	

K	X1
	

D	X5
	
Ø4x35mm	


L	X3
	

E	X36
	
Ø3.5x14mm	


M	X18
	
Ø4x12mm	

F	X6
	
Ø4x10mm	


1





2




3




A	X4	K	X1	M	X2
					

4




B	X4	C	X4
			

5




M	X16

6





C	X4	D	X4

7




J	X12
	


8




D	X1	N	X1
			

9




E	X8	G	X1	L	X1	R	X1
		 G-1	 G-2				



10




E	X2
	

11




E	X8	G	X1	L	X1	R	X1
		 G-1	 G-2				



12




E	X2
	

13




E	X8	G	X1	L	X1	R	X1
		 G-1	 G-2				

14




E	X2
	

15



F	X6	H	X6
			
		H-3	

16



E	X6
	