ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

\mathbf{M}

WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)



- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

HARDWARE IDENTIFICATION

Z-B1 (BOX1) - HARDWARE PACK IS LOCATED IN 204391KE (B1)


1	BOLT (M6 x30mm - BLK)		6PCS	4 FLAT HEAD SCREW (M4 x 32mm - RBW)	8PCS
2	LOCK WASHER (1/4" - BLK)	©	6PCS	5 SMALL ALLEN WRENCH (M4 x 65mm - BLK)	1PC
3	FLAT WASHER (1/4" x13mm - BLK)	0	6PCS	6 BIG ALLEN WRENCH (M5 x 65mm - BLK)	1PC

NOTE:


Philips head screw driver in the assembly process; however, manufacturer does not provide the item

PAGE 3 OF 5


STEP 1




STEP 2



PAGE 4 OF 5



STEP 4 COMPLETE





PAGE 5 OF 5