


**USER'S MANUAL FOR
SLOW RETURN SYSTEM MANUAL SCREEN**





SAFETY GUIDE:


When assembling, DO NOT stand right under the screen.
When mounting the screen, expansion bolts should be firmly punched and properly secured into the wall or ceiling.

SPECIFICATION:

1. Innovative Slow Return System , patented design, ensure quiet controlled return of the screen into its case at rated speed, which provides optimal performance, durability and smooth, safe operation.
2. No assembly required. Suitable for both wall and ceiling hanging.
3. Flat screen surface, flame retardant, no peculiar smell, while offering a quality image.

INNOVATIVE Slow Return System


The patented Slow Return System provides a excellent and smooth operation. Ensuring a quiet controlled return of the screen. Please refer to OPERATION section for detailed instruction to operate.




INSTALLATION METHODS:

Model A: For small size screens

---- wall mounting




---- ceiling mounting




Model B: For large size screens

---- wall mounting



---- ceiling hanging




OPERATION:

1. Pulling down the screen

Pull down the fabric slowly about 50mm lower than the desired position, wait for 3 seconds then let go, the screen will self-lock. When the top black border depletes, do not pull anymore to avoid fabric damage.

2. Retracting the screen

After usage, pull down the fabric a little, then let go, the screen will unlock automatically and fabric will retract back into the case.



FABRIC CLEANING:

The fabric is washable by soft soap and warm water, please do not use alcohol or other solvents to clean the screen.

REMARK:

1. Do not scratch or fold up the fabric
2. After usage, please check again there are no other foreign objectives on the screen surface before retracting the fabric back into its case.