

## MASTER-MARINER

### CLOCK & MOONPHASE INSTRUCTIONS



1. Only fit a new AA 1.5 volt battery that should last at least one year.
2. Fit battery aligned with the polarity icon in the battery compartment and as shown overleaf.
3. Never allow the clock to remain stopped for long with a run down battery. The battery will leak and damage the quartz mechanism.
4. For Quartz clock lightly press and turn the ½” diameter serrated black disc to alter the time.
5. For Moonphase clock lightly press and turn the ½” diameter serrated black disc to alter the setting of the indicator hand to align with the current moon state as obtained from a calendar or other on-line source.

### CLOCK & MOONPHASE INSTRUCTIONS



Hand set button.

Insert battery with polarity this way.

