




Assembly Instructions


TV stand



Parts list:


A  1PC	B  1PC	C  1PC	D  1PC	E  1PC	F  1PC	G  1PC
						H  1PC
						I  1PC
J  2PCS	L  1PC	B2  20PCS	B3  1PC	B4  18PCS	B5  4PCS	
B1  2PCS	M  1PC	B6  20PCS	B7  20PCS	B8  2PCS	B9  4PCS	

Please read this assembly instruction carefully before assembling this unit . It is recommended that this unit should be assembled by two adults.




Note: Please don't over tighten the cam screws. Assure the cam screw fits in the plastic threaded insert. Otherwise, the cam nut might not be able to catch the cam screws.


Step 1:




Step 2:




Step 3:




Step 4:




Step 5:




Step 6:




Step 7:




Step 8:




Step 9:




Step 10:




Step 11:




Step 12



Step 13:



Step 14:



Step 15:

