



Unlock Your World with BenjiLock A Quick Guide



FINGERPRINT
UNLOCK



MULTIPLE
USERS



IP68 WEATHER
RESISTANT



ACCESSIBILITY
FOR ALL



IP68 CE FCC RoHS

MODEL: BJL207SS-40

Welcome

to the BenjiLock Family!

Introducing your new Outdoor Fingerprint Padlock, crafted from our Stainless Steel series. No matter where you go - work, gym, school, home, indoors, or outdoors - the key is always at your fingertips!

Forget Wi-Fi and apps! Your padlock remains non-connected, offering personalized control and peace of mind with fingerprint access. It's your padlock, and yours only!

Are you ready to 🔓: #UnlockYourPotential 🔥? Let's go!

Thanks again!

Robbie Cabral
Inventor of BenjiLock



Robbie Cabral
— Inventor —

P.S. Not a fan of written instructions? We understand, and we've got you covered! Unlock BenjiLock faster and easier with our video guide. Simply scan the QR code below for a step-by-step walkthrough. You'll be unlocking BenjiLock in no time!



Ready to experience the security and convenience of BenjiLock? Here's how to set up your Stainless Steel Outdoor Fingerprint Padlock in just a few simple steps:

1. Open and Unlock:

- ▶ Start by opening the bottom protective cover of your BenjiLock.
- ▶ Touch the fingerprint sensor to unlock it – this activates the setup process.

2. Register Your Fingerprint (as the Primary User):

- ▶ Within 5 seconds, press and hold your preferred finger on the sensor until it turns blue, beeps, and flashes.
- ▶ Repeat this touch-and-hold action 5 times. Each touch will be confirmed with a beep.
- ▶ Keep holding until the blue LED turns solid, indicating your fingerprint is stored as the primary user.

Note: If a red LED appears during registration, no worries! Repeat step 2 until you witness 5 successful blue LED lights, accompanied by a solid flash and a reassuring beep sound.

Close the shackle and firmly secure the protective cover.

Congratulations, your BenjiLock is now ready for use!



www.BenjiLock.com



© 2024 BenjiLock, LLC. All Rights Reserved.
BJL207SS-40-MRB-REV1



Ready to grant access? Here's how to add a new fingerprint or user to your BenjiLock in a few simple steps:



Ready for a fresh start? Here's how to factory reset your BenjiLock in a few simple steps:



Tips for a more personalized BenjiLock experience:

What's Inside:



1. Unlock and Verify:

- ▶ Begin by unlocking your BenjiLock with the original fingerprint (the primary user).
- ▶ Touch the sensor again with the same primary fingerprint and hold for 5 seconds until the blue LED flashes, confirming your authorization to add a new fingerprint or user.

2. Enroll the New Fingerprint or User:

- ▶ Within 5 seconds, have your new fingerprint or the new user press and hold their preferred finger on the sensor 5 times.
- ▶ Each touch is acknowledged with a beep.
- ▶ Hold your new fingerprint or user until the blue LED turns solid, indicating successful registration.

Secure the protective cover and close the shackle. Congratulations! The BenjiLock is now accessible for your new fingerprint or the new user to unlock with their fingerprint.



Your unique code (engraved on the left of your BenjiLock) is your key to exclusive offers, news, and exciting updates. Simply register your code online to unlock a world of BenjiLock benefits!



Rest easy knowing your BenjiLock is covered! Enjoy the peace of mind provided by our 1-Year Limited Warranty.

1. Unlock with Primary User:

- ▶ Unlock and release your BenjiLock using your original stored fingerprint (the primary user).

2. Activate Reset Mode:

- ▶ While the BenjiLock is unlocked, press and hold the fingerprint sensor for 5 seconds using your primary user's finger.
- ▶ The LED will flash blue and emit a beep. Continue pressing and holding.

3. Complete Reset:

- ▶ While maintaining continuous pressure on the fingerprint sensor, within 5 seconds of the blue flash, the LED will emit another beep and turn solid red after a few seconds.
- ▶ This confirms a complete reset. You may now release your finger from the sensor.

Close the shackle, and congratulations! Your BenjiLock is now reset, and all users have been erased.

- ▶ While your BenjiLock comes partially charged, a full charge is recommended for first use. The built-in LED light will turn from red (charging) to blue (charged) after about 10-15 minutes. Your battery will last up to a year on a single charge.
- ▶ For optimal performance, ensure your finger is clean and dry when registering.
- ▶ Place your finger flat on the sensor for optimal recognition.
- ▶ You can register your fingerprint from multiple angles (side, top, bottom) for even better recognition! This helps account for natural finger placement variations.
- ▶ Using the same fingerprint to unlock your BenjiLock on multiple occasions can improve the success rate of fingerprint recognition.
- ▶ You can register additional fingerprints or multiple users (up to 10) as the primary user.
- ▶ For enhanced security and convenience, we recommend the primary user always add multiple fingerprints as a backup.
- ▶ Your BenjiLock can operate within a temperature range of -20°C (-4°F) to 70°C (158°F) and is IP68 certified for excellent water and dust resistance.
- ▶ When your BenjiLock is low on battery, it will flash red three times and emit a beep upon opening, indicating the need for recharging.

- ▶ If the battery is drained due to no usage over a period of time, a USB-C charger is included for convenient recharging. A few seconds of charging with a power bank (not included) will give you a jumpstart to unlock.
- ▶ Remember, resetting your BenjiLock will erase all stored fingerprints. You'll need to re-register any fingerprints you want to use again.

To register your new BenjiLock for exclusive offers, and explore the entire collection, latest news, merchandise, events, reach out to Robbie, or seek help with your product, including usage instructions and FAQs, please visit BenjiLock.com.

