


# Assembly Instructions



## 48" SOFA TABLE WITH 2 DRAWERS

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

### COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
		Hardware Bag	1 pce
		Table Top	1 pce
		Legs	4 pcs
		Fixed Shelf	1 pce

### HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Hex Bolt	8 pcs
2		Pan Head Screw	4 pcs
3		Lock Washer	8 pcs
4		Flat Washer	8 pcs
5		Wrench	1 pce


This product will take 15-20 minutes to assemble.

#### Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

#### NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.




# Assembly Instructions

## 48" SOFA TABLE WITH 2 DRAWERS

### ASSEMBLY :


#### STEP 1

- 1.1-Pull out the Drawer out and Turn the Table Top upside down on a protective surface such as carpet or other soft materials as shown in the Fig1.
- 1.2-Attach three legs randomly to the Table Top Using Flat Washer(3), Lock Washer(2), Hex Bolt(1) and Wrench(4).
- 1.3- Do not fully thighten bolts.
- 1.4-Insert the fixed shelf into the 3 legs as shown in the Fig1.



#### STEP 2


- 2.1-Insert the last leg to the corner of apron frame and Fixed Shelf. Then tighten with Using Flat Washer(3), Lock Washer(2) and Hex Bolt(1) using the Wrench(4) provided.
- 2.2- Insert and tighten the Pan Head Screw(5) using a screw-driver (Not included) into the Fixed Shelf to scure Shelf as shown on Fig.2



**Fig.2**

#### STEP 3

- 3.1- Turn table to upright position.
- 3.2- Balance table by applying gentle downwards pressure to table Top (B). As shown on fig.3
- 3.3- Once sofa table is fully balance fully tighten all bolts.



**Fig.3**

#### CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.