


|Cabinet

Assembly Instruction - Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



CONTACT US

· In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important - Please read these instructions carefully before starting the installation.

V1.0

EN

Before Assembly



Thank you for choosing our product!

To ensure a smooth installation process, please read this guide carefully to familiarize yourself with the required tools, materials, and installation steps. Follow the relevant sections to avoid any damage caused by improper installation, and make sure to review all operation and safety guidelines for correct installation procedures.

Packaging Notice:

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.

Safety and Care Advice



Important :

Please read these instructions fully before starting assembly.

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

Warning

In order to help prevent overturning, please follow these instructions.

- Use the anti-tip strap or wall fixing method provided (if applicable).
- Do not allow children to climb or hang on the furniture.
- Do not open more than one drawer at a time.
- Do not place heavy items in the top drawers.
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose.
- Please note that only the anti-tip strap is provided. You will need to provide wall plugs and screws applicable for your wall type.

Customer Service Guide



Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6×30mm screws.”

Contact Us:

By Email:

Send an email with the subject line “Missing Parts Issue.” Include the following in the email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team.
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Contact Us:

Customer Service Email

Helpful Tips

To process your issue efficiently, please prepare the following information:













- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.

Thank you for your trust and support!
We hope you enjoy using our product!

Parts List - Panels





Please check you have all the panels listed below.

		
1 796x400x15mm x1	2 796x400x15mm x1	3 650x399x15mm x1
		
4 650x399x15mm x1	5 764x60x12mm x2	6 340x120x25mm x2
		
7 646x80x15mm x1	8 758x212.5x15mm x3	10 300x160x12mm x3
		
11 715x160x12mm x3	12 287x60x12mm x3	13 725x297x3mm x3

Parts List - Panels



Please check you have all the panels listed below.

	
14 300x160x12mm x3	15 660x774x3mm x1

Parts List - Fittings



Please check you have all the fittings listed below.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied are required.

 A Ø15X9.5mm x38+3	 B Ø6.5X35mm x38+3	 C Ø8X30mm x14+1
 D Ø3.5X12mm x36+3	 E Ø4X35mm x22+1	 F Ø4X19mm x6+1
 G Ø20X23mm x6	 H L=300mm x3	 H L=300mm x3
 H L=300mm x3	 H L=300mm x3	 I Ø3X14mm x12+1Set
 J 70X30X5mm x1	 K Ø21mm x12+1	 L x1Set
 M 763X35X15mm x1	 N M6X25mm x3+1	 O M6X12mm x2+1

Parts List - Fittings







Please check you have all the fittings listed below.


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied are required.

Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Assembly Instructions



Step 1




(D)	X18
$\phi 3.5 \times 12 \text{mm}$	


(H)	X3
L=300mm	

(H)	X3
L=300mm	



Use screw (D) to fix accessory (H) onto boards (3) and (4), as shown in the figure.




Step 2





Install accessory (B) onto panels (3) and (4), as shown in the figure.



Step 3



Connect panel (5) with panels (3) and (4), secure it with fitting (A), and then cover the holes with fitting (K). Then use screw (O) to pass through fitting (M) and connect with panels (3) and (4).



Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

Step 4



(B)	X11
ø6.5*35mm	

Install accessory (B) onto panels (2) and (6), as shown in the figure.




Step 5




(C)	X4
ø8*30mm	

(E)	X4
ø4*35mm	


Insert accessory (C) into the holes of panels (3) and (4), and use screw (E) to pass through panel (2), connecting it with panels (3) and (4).



Step 6



Connect panel (7) with panel (6), and secure it with fitting (A).





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

Step 7



Insert accessory (C) into the corresponding hole of panel (2), connect it with panels (6) and (7), and secure it with accessory (A).



After installation, flip it over.


Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

Step 8


Vertically insert panel (15) into the grooves of panels (3) and (4).



Step 9



Install accessory (B) and accessory (L) onto panel (1), as shown in the figure.




Step 10



(A)	X4	(C)	X4	(K)	X4	(N)	X3
Ø15*9.5mm		Ø8*30mm		Ø21mm		M6*25mm	

Insert accessory (C) into the holes of boards (3) and (4), then align and insert vertically into board (1). Use accessory A to secure it, as shown in the picture. Cover the holes with accessory (K). Then use screw (N) through accessory (M) to connect with board (1).



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

Step 11



(I)	X12
Ø3*14mm	

Insert the plastic buckle into the back plate slot, screw through the hole in the plastic buckle and lock it in place.




Step 12




(B)	X15	(E)	X18	(F)	X6	(G)	X6
Ø6.5*35mm		Ø4*35mm		Ø4*19mm		Ø20*23mm	



Use screw (E) to fix panels (10), (11), (12), and (14) together, and insert panel (13) as shown in the diagram. Install accessory (B) on panel (8), and then use screw (F) to connect panel (8) with accessory (G).



Step 1



Step 2



Step 3


X3

Step 13



(A)	X15
Ø15*9.5mm	

Connect panel (8) with panels (10), (12), and (14), and secure it with accessory (A).




X3

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

Step 14



Step 15



Step 16

Align drawer (8) with the slide rail grooves in order and insert them one by one; the cabinet installation is complete.

