


ACCENT CHAIR



PRE-ASSEMBLY INFORMATION

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

NOTICE

- Please keep this manual and hand it over when you transfer the product.
- Please read the following instructions carefully and use the product accordingly.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.
- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Please assemble the item in a spacious room and do not place the unwrapped product directly on the ground to avoid damage.
- Do not use this item in a way inconsistent with the manufacturer' s instructions as this could void the product warranty.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (films, plastic bags and foam,etc.) away from children and pets.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Do not expose product to direct sunlight exposure or rain,and do not put it in a humid place. Failure to do so may accelerate the distortion or discoloration.



TWO PERSON ASSEMBLY



UP TO 30 MINUTES
FOR ASSEMBLY





WEIGHT LIMITATION
380LBS

IMPORTANT


1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping.
3. Please use hand tools to assemble this product. If you're using power tools, remember to set the tool to low torque to avoid damage.
4. We recommend open the vacuum sealed cushions and pillows after the sofa frame is installed.

COMPONENTS



x4

I Knob
M8*50mm



x2

J Bolt
M8*20mm




x4

L Flat Washer



x1










M Allen Key



**TOOLS
REQUIRED**

The hardware quantities listed above are required for proper assembly. Some extra bolt and washer may also have been included.



COMPONENTS



ASSEMBLY STEPS

1




Slightly unloose the screws from arms. Attach Front Panel D to Arms A&B and tighten the screws.




2

Open the zippers, align the arms with the holes and attach with Knobs I. Do not fully tighten Knobs before the Back Panel E is installed.

I X4






NOTE: Screw in all Knobs and then start to tighten.



3





Attach the Seat Panel F to the frame and secure it in position.



4



Attach the Back Panel E to Arms with Bolts J. Fully tighten Knobs I.

J X2




5

Screw in legs K and Washers L clockwise until secure.




6

Use scissors to open all the vacuum sealed cushion and pillow. It may take 24-72hrs to fully expand back to its original shape & firmness.



7

Place the back pillow and cushion into position. Congrats! Enjoy your new chair.



RETURN POLICY

Thank you for purchasing a product. We do our best to ensure your furniture arrives without any problems, but occasionally mistakes happen—as humans we are imperfect beings. In the event that a part is damaged or missing, we will be more than happy to provide you with replacement part(s) for free. Please contact us or go to our contact page. All your concerns will be taken good care of by our CUSTOMER SERVICE TEAM.

All items can be returned for any reason within 60 days of the receipt and will receive a refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. Once a returned item has been received Direct, refunds or replacements will be processed within 5 business days.

All returns must be shipped back in original boxes and shipped back to Return Center at the customer's expense. Pictures may be required for some returns to ensure an item is not damaged prior to its return. If the reason for return is a result of an error by us then Direct will provide a pre-paid shipping label via email. New boxes for return will not be provided by Direct, and need to use the original shipping boxes. Items received without original boxes may not be accepted or may increase your return processing time.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.