




3



Model: \_\_\_\_\_  
Lot No: \_\_\_\_\_  
Date of Purchased: \_\_\_\_\_

## ACCENT CHAIR




### ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free customer service number and have this assembly manual open to the parts list ready to provide the model name, and part name or number.




## PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.




Allen Key  
1x



Bolt  
8x



Washer  
8x




Left Right


Rear Legs  
2x



Front Legs  
2x




Backrest  
1x



Seat  
1x

## ASSEMBLY INSTRUCTIONS

1



2

