Please save this manual for future reference.

Product Name:	Modern Gray 37.4" Tall 4-Drawer Chest	

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. Place all wooden furniture parts on a clean, flat, soft surface to prevent scratches. Refer to the steps provided below for assembly.


Do not attempt to assemble or use the product if any parts are missing or damaged.


CARTON CONTENTS:

Hardware:

A*8	B*6	C*6	D*8	E*1
		0	0	

Parts:






Tools required for assembly: Screwdriver (if using power tools, use with care)


Product Name:	Modern Gray 37.4" Tall 4-Drawer Chest	

Assembly:

Step 1 – Insert the metal legs 2 into rails 3 as shown below.




Step 2 – Secure the legs from the assembled leg frame in Step 1 by using screws A, washer D and screwdriver E to secure the frame as shown below.



Please save this manual for future reference.

Product Name:	Modern Gray 37.4" Tall 4-Drawer Chest	

Step 3 – With 2 people, carefully place the chest body upside down on a clean and soft surface to prevent scratching the top. Secure the frame from the assembled leg frame in Step 2 by using screws B, washer C, and screwdriver E to the chest (1), as shown below.



Step 4 – With 2 people, carefully flip the table upright and gently shake it to ensure it is stable. Tighten hardware as needed. Assembly completed. Your 4-drawer chest table is now ready for use!



Warning: DO NOT sit or stand on the chest as this may damage the product and cause serious bodily injury.