

ZFK023



INSTRUCTION MANUAL


18
15
17
24
24
16
15
1
9
7
3
22
21
23
20
10
10
3
19
14
14
4
4
13
12
5
2
11
8
6

ASSEMBLY INSTRUCTIONS

Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.


Identify each component and refer to the provided assembly diagram or step-by-step instructions.

Assemble the furniture in the order specified to ensure proper alignment and fit.


Use the provided tools or recommended tools for assembly. Do not use excessive force when tight ening screws or bolts.

If any difficulties arise during assembly, consult the troubleshooting section or contact our custom– er support.

Tools Required












Screwdriver








Hammer




Board parts List


NO.	PICTURE	QTY
①	 Front Panel	1
②	 Bottom Panel	1
③	 Fixed Shelf	2
④	 Adjustable Shelf	2
⑤	 Lower Left Side Panel	1
⑥	 Lower Right Side Panel	1
⑦	 Upper Left Side Panel	1
⑧	 Upper Right side Panel	1






NO.	PICTURE	QTY
⑨	 Back Support Strip	1
⑩	 Back Panel	2
⑪	 lower door panel	1
⑫	 Flip-Up Door Panel	1
⑬	 Flip-Up Door Bottom Panel	1
⑭	 Flip-Up Door Shelf	2
⑮	 Upper Cross Strip	2
⑯	 Pegboard	1

NO.	PICTURE	QTY
⑰	 Upper Base Panel	1
⑱	 Upper Roof Panel	1
⑲	 Drawer Front Panel	1
⑳	 Left Drawer Side Pane	1
㉑	 Right Drawer Side Panel	1
㉒	 Drawer Back Panel	1
㉓	 Drawer Bottom Panel	1
㉔	 Center Cross Strip	2

Hardware parts List


NO.	PICTURE	QTY
Ⓐ	 2-in-1 Bolt Φ6*33	44+1
Ⓑ	 2-in-1 Nut Φ15*12	56+1
Ⓒ	 Wooden Dowel Φ8*30	28+1
Ⓓ	 Self-tapping Screw ø3.5*12	16+1
Ⓔ	 Self-tapping Screw ø3.5*30	4+1
Ⓕ	 Pull Handle	4
Ⓖ	 Pull Handle Bolt M4*18mm	8+1

NO.	PICTURE	QTY
Ⓒⓛ	 Left Cabinet Slide Rail	1
Ⓒⓡ	 Right Cabinet Slide Rail	1
Ⓓⓛ	 Left Drawer Slide Rail	1
Ⓓⓡ	 Right Drawer Slide Rail	1
Ⓘ	 Double Headed Bolt L=48	4+1
Ⓙ	 2-in-1 Nut Φ15*10	4+1
Ⓚ	 Tumbler Hardware	1


NO.	PICTURE	QTY
Ⓛ	 Anti-tipping Hardware	2
Ⓜ	 Ventilated Cover	2
Ⓝ	 Self-tapping Screw ø3*16	32+1
Ⓞ	 Back Panel Fastene	8+1
Ⓟ	 Perfect Post	56+1
Ⓠ	 Laminated Particle	8+1
Ⓡ	 Door Hinge	2
Ⓢ	Self-tapping Screw	3
Ⓣ	 2-in-1 Bolt Φ6*26	4+1

STEP 1

Lower Left Side Panel	
5	X1




Lower Right Side Panel	
6	X1



300mm Left Cabinet Slide Rail	
CL	X1





300mm Right Cabinet Slide Rail	
CR	X1



ϕ3.5*12 Self-tapping Screw	
D	X6







STEP 2

Stationary Ladle	
1	X1




Front Panel	
2	X1



Back Support Strip	
9	X1



Upper Cross Strip	
15	X1




2-in-1 Bolt Φ6*33	
A	X6



2-in-1 Nut Φ15*12	
B	X6




Perfect Post	
P	X6




STEP 3

Back Panel	
10	X2

Ventilated Cover	
M	X2





STEP 4

Fixed Shelf	
3	X2

Lower Left Side Panel	
5	X1


Lower Right Side Panel	
6	X1

2-in-1 Bolt Φ6*33	
A	X18

2-in-1 Nut Φ15*12	
B	X18

Wooden Dowel Φ8*30	
C	X16


Perfect Post	
P	X18



STEP 5

Upper Base Panel	
17	X1
Center Cross Strip	
24	X2


2-in-1 Bolt Φ6*33	
A	X4
2-in-1 Nut Φ15*12	
B	X4
Perfect Post	
P	X4



STEP 6

Upper Cross Strip	
15	X1
Upper Roof Panel	
18	X1

2-in-1 Bolt Φ6*33	
A	X2
2-in-1 Nut Φ15*12	
B	X2
Perfect Post	
P	X2



STEP 7

Upper Left Side Panel	
7	X1


Upper Right side Panel	
8	X1


2-in-1 Bolt Φ6*33	
A	X14

2-in-1 Nut Φ15*12	
B	X14

Wooden Dowel Φ8*30	
C	X8

Perfect Post	
P	X14






STEP 8

Double Headed Bolt L=48	
I	X4

2-in-1 Nut Φ15*12	
B	X8

Wooden Dowel Φ8*30	
C	X4

Perfect Post	
P	X8




STEP 9

Pegboard	
16	X1

ϕ3.5*12 Self-tapping Screw	
D	X8


ϕ3*16 Self-tapping Screw	
N	X8

Back Panel Fastener	
O	X8



STEP 10


Tumbler Hardware	
K	X2



STEP 11

Flip-Up Door Panel	
12	X1


ø3.5*16 Self-tapping Screw	
N	X6
Pull Handle	
F	X2
M4*20mm Pull Handle Bolt	
G	X4
Tumbler Hardware	
K	X1



STEP 12


Flip-Up Door Bottom Panel	
13	X1
Flip-Up Door Shelf	
14	X1

ø3.5*16 Self-tapping Screw	
N	X6



STEP 13


Tumbler Hardware	
K	X2




STEP 14

Flip-Up Door Shelf	
14	X1


ø3.5*16 Self-tapping Screw	
N	X2




VII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment



In-and-Out
by loosening the hinge-arm mounting screw or via cam adjustment




Vertical
Via slots in the mounting plate or via cam adjustment

STEP 15

Adjustable Shelf	
④	X2
lower door panel	
⑪	X1

Ø3.5*16 Self-tapping Screw	
N	X12
Pull Handle	
F	X1
M4*20mm Pull Handle Bolt	
G	X2
Door Hinge	
R	X2
Laminated Particle	
Q	X8




STEP 16

Left Drawer Side Pane	
20	X1

Right Drawer Side Panel	
21	X1


Drawer Back Panel	
22	X1

ø3. 5*30 Self-tapping Screw	
E	X4



STEP 17


Drawer Bottom Panel	
23	X1




STEP 18

Drawer Front Panel	
19	X1


2-in-1 Bolt Φ6*26	
T	X4
Φ15*10 2-in-1 Nut	
J	X4
Pull Handle	
F	X1
M4*20mm Pull Handle Bolt	
G	X2
Perfect Post	
P	X4






STEP 19

ø3.5*12 Self-tapping Screw	
D	X6
300mm Left Drawer Slide Rail	
DL	X1
300mm Right Drawer Slide Rail	
DR	X1



STEP 20

Self-tapping Screw	
S	X3



Important Safety Tips

Important Safety Tips


1.This product is a narrow and tall cabinet, which has the possibility of tipping over under undue external force (e.g., children climbing), or under extreme circumstances (e.g., earthquakes). Especially narrow and tall cabinets with drawers are extremely prone to tipping over and becoming dangerous when multiple drawers are opened.


2.For safety reasons, it must be secured to the wall by means of an anti-tipping device when in use, so as to avoid serious consequences due to the tipping of the cabinet.

3.Please use the anti-tipping device that comes with the package, fix one end on the wall and the other end on the back of the product on the border or other thick location, and tie it tightly with a nylon strap.

4.There are long screws, expansion tubes, short screws, nylon straps and fixing buckles inside the anti-tipping device, if you don't find the matching anti-tipping device in the package, please contact our customer service staff immediately for your replacement.

5.Regardless of the fixtures used, parents are asked to keep an eye on their children and not to climb or shake the product violently to avoid danger.






How to use the anti-tipping device

1.Use expansion tubes and long screws to secure the plastic parts to the wall.

2.Use self-tapping screws to attach the plastic parts to the back of the furniture (Located in thick areas such as panels, back panel edges, etc).

3.Pass the nylon tie through the two holes, tie it tightly, and cut off the excess.



MAINTENANCE AND CARE

Clean regularly using a soft brush or vacuum with a brush attachment. Avoid harsh chemicals or abrasive cleaners.
Wash with a hose or pressure washer on a low-pressure setting for heavy soiling. Rinse thoroughly afterward.
Ensure proper drying after cleaning or exposure to rain to prevent mold or mildew growth.
Protect from extreme weather by moving furniture to a covered area or using furniture covers or tarps.
Avoid dragging or placing heavy objects on the furniture to prevent damage.
Apply UV protection spray or furniture wax to prevent fading and damage from the sun.
Regularly inspect for wear, loose strands, or damage and address issues promptly.

WARRANTY INFORMATION

Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.

Warranty Claim Process

To initiate a return on Amazon, please follow these steps:

1. Log into your Amazon account and go to the "Your Orders" section.
2. Locate the order containing the item you wish to return.
3. Contact our customer service for assistance in obtaining a prepaid return label.
4. Once you receive the return label, securely affix it to the package.
5. You can then choose to drop off the package at a designated carrier location or arrange for a pickup.
6. After we receive and inspect the returned product, we will initiate the refund process.
7. The refund will be credited back to the original payment method used during the purchase.
8. Typically, refunds are processed within 3-5 business days.



Contact Information

If you have any questions, concerns, or need assistance,
please reach out to our customer support team using the contact information provided below:

Customer Support Email

support@sunvivi.com