




**PET MARVEL®**



**Auto Pet Water Fountain  
[Mini/Mini Stainless]**

# Welcome

Thank you for choosing PET MARVEL.

This user manual will guide you through the Auto Pet Water Fountain [Mini], including the installation, usage, as well as the maintenance of the product, aiming to help users get the best experience of the product.

If you have any questions during use, please contact our customer service via the hotline or email as below. PET MARVEL's technical support experts will be happy to assist you.

✉ Email: [customerservice@petmarvel.com](mailto:customerservice@petmarvel.com)

You can scan the QR code or search for "PET MARVEL" in the App Store/Google Play to download the app and unlock more product features.



Scan to download App

**TECHNOLOGY  
CARES FOR PET  
HEALTH**

# 1 Information For Users

## User Instructions

- Please read this manual carefully before using the product and keep it in a safe place.
- Failure to comply with the following terms may result in improper functioning of the product or other unforeseen damages.
- Please strictly follow the instructions in this manual for installation and use of the device. Product failures or damages caused by operations not covered in this manual are not covered under the warranty.

## Safety Instructions

- Before using the device, thoroughly rinse the filter with clean water and soak it. Do not rinse the filter with overly hot water.
- To maintain optimal filtration, replace the filter when the filter indicator light turns on. Clean the water tank weekly, and regularly inspect and clean the parts.
- Do not fill the water beyond the maximum water level.
- Never allow the device to run dry while powered on, as this can damage the water pump.
- To prevent pets from knocking over the device, it's recommended to place it in a corner or against a wall.
- Do not disassemble, modify, or attempt to repair the device yourself, as this will void the warranty and all after-sales services.
- Use the device indoors only. Keep it out of direct sunlight.
- Before disposing of the device, be sure to remove the battery.
- When removing the battery, ensure the device is powered off. Disconnect the power cord, open the top cover, and take out the battery.
- Dispose of the battery safely.
  
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.

- This appliance must only be supplied at safety extralow voltage corresponding to the marking on the appliance.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

“This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

- Radiation Exposure Statement:


1.This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

2.The device has been evaluated to meet general RF exposure requirement

“Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment”.

## 2 Product Information



### Filter Indicator Light:

Orange breathing light flashing:  
Filter needs replacement


### Status Indicator Light:

Solid white light: Water dispensing in progress  
Solid red light: Low battery  
White light flashing: Charging in progress


## ③ Packing List

### Notice


- After unpacking the product, please check if the product is in good condition and verify that all accessories are included as shown in the diagram below.
- As the product may undergo updates and iterations, some accessories may vary. Please refer to the actual items received.




Water Tank \*1



Main Unit \*1



Filter \*1



User Manual \*1



Type-C Power Cable \*1

## 4 Usage Instructions

### Installation Instructions

1. Pour clean drinking water into the water tank, ensuring that the water level does not exceed the maximum level line.
2. Sequentially install the filter cartridge, filter, and water tray onto the water tank. (Before use, rinse the filter with clean water and soak it for two minutes to remove any floating carbon particles caused by movement during transport.)
3. Attach the main unit by inserting it into the side port of the water tank, pressing down firmly to secure it in place.

### Power On/Off



Press and hold the power button for 3 seconds to turn the device on or off.

### Water Dispensing

When powered on, the water fountain will dispense water immediately, followed by a water dispensing cycle every 60 minutes.

Additionally, the fountain will dispense water immediately when it detects nearby movement in front of the unit.


If the water level falls below the marked line, please refill the water tank with an adequate amount of drinking water.



### Replacing the Filter


To ensure effective filtration of impurities, replace the filter when the filter indicator light turns orange. After replacing the filter, press and hold the reset button to reset the filter indicator. A rapid flashing of the filter indicator light confirms that the reset was successful.

**Note:** The filter must be reset once during the initial use.



### Anti-Tip Feature


To prevent pets from knocking over the device, you can extend the anti-tip stands on both sides of the water tank to help stabilize the water fountain.



### Charging

When the indicator light turns red, please connect the charger immediately to ensure normal operation.

A flashing indicator light indicates that the device is charging, and the light will turn off once charging is complete.




## 5 Maintenance and Care

### Cleaning

The water tank can be removed for washing; allow it to dry completely before reusing.

**Note:**The main unit should not be washed with water. Please use a damp paper towel to clean it.



## 6 Product Specifications

Product Name: Auto Pet Water Fountain [Mini/Mini Stainless]

Product Model: NFNWAWS12A

Main Material: ABS,SUS304

Product Size: 257\*150\*184mm

N.W.: [Mini] ≈0.83kg / [Mini Stainless] ≈0.88kg

Input: 5V---1A

Battery Capacity: 5000mAh

Product Grade: Qualified

---

R-R-pML-NFNWAWS12A

## **7** Warranty Terms

Dear customers, thank you for purchasing this product, please read the below warranty terms carefully before using:

### **12-month Warranty & Lifetime Customer Support**

Only apply to eligible purchases made directly from the Pet Marvel authorized distributors. Warranty coverage applies to the original owner and the original product only. And is not transferable.

The following conditions are not covered by the warranty:

- Any malfunction or defect caused by improper use of environment or conditions;
- Any fault or defect caused by improper installation, misuse, unauthorized maintenance, force majeure events, or other external reasons;
- Any fault or defect caused by the use of non-original fittings or accessories;
- The product has exceeded the warranty period;
- Other failures or damages caused by none of the product design, technology, manufacturing process, or quality problems;
- Normal fading, wear and tear, or consumption during the use of the product;
- Not able to provide a valid purchase certificate.

**For warranty service and more information, please get in touch via  
Email: [customerservice@petmarvel.com](mailto:customerservice@petmarvel.com)**



Note: Pictures on this brochure are for reference only, and the product is subject to the real object.

---