
"C" SIDE TABLE



Thank you for purchasing the "C" SIDE TABLE. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Please unwrap your piece carefully, ensuring it is as close as possible to point of use. **Take care when lifting** to avoid personal injury and (or) damage to the product.

Care and Maintenance for Wood

We recommend dusting surfaces with a clean, soft, dry or slightly damp cloth.

Always clean the surface by rubbing in the direction of the grain.

We recommend polishing your furniture twice a year with a non-silicone cleaning agents or polish to clean the surfaces of this product.

Waxes should be avoided because their regular use may result in a build-up of wax film on the surface of the furniture.

Remove liquid spills promptly.

Be sure to use pads under hot or very cold dishes, beverages, vases, etc. to protect the furniture surface.

Please note long periods of heat or excessive dampness can cause splitting, warping and swelling in solid wood.

Keep away from direct sunlight.

Please ensure leaflet is read in full and retained it for future reference.