


DEXNUMP

Ceiling fan with light



Dexnump-service@hotmail.com

Welcome to Dexnump. Thank you for choosing our products, if you have any problem or advise, please feel free to contact us.
You can also contact us to get a new product trial.

DEXNUMP

Product parameters

| | |
|-----------------|--|
| Material | Iron, aluminum, copper |
| Product size | Ø20" |
| Boom length | 4", 8" |
| Motor power | 16W |
| Light source | (US) E26 or E12 bulb (Not included) |
| Working voltage | Input AC85-265V, Output DC24V |
| Rotating speed | Forward and reverse 1-6 gears |
| Certification | All electric components are complied with CE/ ROHS/ FCC approval |




Warranty


1. Dexnump provides 24 months warranty for this product since the purchased date.
2. During the warranty period, Dexnump provides refund or replacement without charge if you have any using problem.




WARNING: We suggest you to hire a professional electrician to complete the installation. Improperly installation may cause the ceiling fan to loosen and even fall.




LED0022-1




LED0022-2 (E12)




LED0022-3



LED0022-5









LED0022-4



LED0022-6

ACCESSORIES



- 1 On/off
- 2 Light switch
- 3 Forward rotate
- 4 Natural wind
- 5 Reversal rotate
- 6 Match code/ fan switch
- 7 wind speed
- 8 Fan timer

INSTALLATION STEPS



- 1 Choose a 10cm or 20cm boom, insert the wire, and fix the boom.



- 2 Pass the two covers through the boom.



- 3 Use the attached screws to fix the U-shaped hanging plate to the ceiling



- 4 Fix the ceiling fan to the U-shaped hanging plate.



- 5 Connect the wires from the controller to the ceiling light (Connect wires of the same color)



- 6 Insert the controller into the middle of the U-shaped hanging plate.



- 7 Connect the live, ground and neutral wires. (White wire-live wire, black wire-zero line, copper Wire: ground wire) Move the large cover towards the ceiling to cover all the accessories on the ceiling. Rotate the cover 5° clockwise to secure it.