


Dining Table Assembly instructions



Pre-Assembly:

- Please read all the instructions carefully and completely before assembly.
- Remove all parts and hardware from box along with any plastic protective packaging. Do not discard any contents until after assembly is completed to avoid discarding small parts or hardware accidentally.
- For your convenience and ease, assembly by two people is strongly recommended.

Parts Included:

- (1) table top (A)
- (1) table base (B)

Hardware Included :

- (8) Bolt (C)
- (8) Flat washers (D)

Tools Needed

- screw driver

Assembly Instructions:

1. Carefully lay the tabletop (A) upside down on a carpeted or scratch-free surface.
2. Align the table base (B) to the cross frame top
3. Insert the flat washer (D) into long bolt. Attach the long bolt with washer into the pre-drilled hole, and tighten bolt with screw driver.

Care instructions:

- This item is intended for indoor use only. To prevent fading, avoid placing item in direct sunlight.
- Clean with a dry cloth.
- Wipe up spills immediately.
- Avoid the use of cleaners or abrasives as they may damage the finish.
- To prevent marking, do not write directly on surface.
- To prevent discoloring, do not use rubber-based place mats.
- Do not place hot plates/cups or cold drinks directly on the surface.
- Assembled furniture should be tightened periodically to avoid damage. DO NOT OVER-TIGHTEN.

Thank you for your purchase