

VIVOHOME

THANK YOU!

NOTE:

To continuously improve its products, VIVOHOME reserves the right to modify this information without prior notification.

For any questions regarding assembly, please watch the video on the product page or contact our customer service. Our customer service will gladly assist you with any additional questions, comments, or concerns.

Thank you for using VIVOHOME products in your home!

Thank You for Purchasing from


VIVOHOME

Made in China

VIVOHOME

HOW-TO

USER MANUAL



Motorized Projector Screen

Assembly is EASY!

**WE WANT
YOU TO
ENJOY LIFE
AT HOME**

GO TO THE PRODUCT LISTING PAGE
FOR AN INSTRUCTIONAL VIDEO!

CONTENTS

Operating Instructions	2
Screen Care Instructions	2
Part List	3
Remote Control Manual	3
Installation	4
Warning	5
Warranty	6

Operating Instructions



TO LOWER THE SCREEN

Press the "DOWN" button, and the screen will lower automatically.

TO RAISE THE SCREEN

Press the "UP" button, and the screen will raise automatically.

TO STOP THE SCREEN

Press the "OFF" button to stop the screen at any desired position.

NOTE:

Please keep the wired control in the "OFF" position when not in use.

Part List



1 PC	1 PC	2 PCS	2 PCS	2 PCS

Screen Care Instructions



1. Before rolling the screen into its metal frame, ensure the surface is free of insects, dirt, or debris.
2. The screen can be adjusted as needed, but avoid running it up and down continuously to prevent motor overheating. Allow the motor to cool down before operating it again.
3. The motor does not require lubrication.

PROTECT YOUR SCREEN

For optimal performance and longevity, always store the screen rolled into its protective metal frame when not in use. Before rolling it back into the frame, inspect both the front and back surfaces to ensure they are free of dust, dirt, or other particles. Use a soft cloth to gently remove any debris.

Remote Control Manual



CODE MATCHING:


1. Press and hold the "Stop" button for 3 seconds to turn off the indicator light.
2. Immediately press any other button to turn the indicator light back on. The matching process is now complete.

CODE CLEARING:


1. Plug in the power supply. The indicator light will turn on.
2. Press and hold the "Stop" button for 10 seconds. The indicator light will begin to flash.
3. Release the "Stop" button to complete the code-clearing process.

**WALL MOUNTED**

The key rings on both ends of the screen's bracket are used for wall mounting. To hang the projection screen, hammer nails or install screws at the appropriate positions on the wall, then hang the screen by the key rings.

**CEILING STYLE**

For ceiling mounting, first install two pothooks at the desired positions on the ceiling. Then, latch the hanging jack on the end cap of the projection screen onto the pothooks.



1. Take out the screen after opening the carton, but be careful not to press on, bump, or damage the screen.
2. Adjust and affix to a wall shelf securely and according to the measurements of your space. (Note: The two wall shelves must be level to avoid a slight slope in the screen surface.)
3. Hang the screen on the wall shelf.
4. After turning on the power, the directional red light will illuminate, activating the up and down switches. You can then begin operating the screen normally.
5. The screen can be controlled either remotely or manually, giving you flexibility in operation. (Please be cautious not to damage the remote control.)



When using your video equipment, Please follow basic safety precautions.

1. Read and understand all instructions before using.
2. Position the cord properly to prevent tripping, pulling, or contact with hot surfaces.
3. If using an extension cord, ensure its current rating is equal to or higher than the appliance's. Using a cord with a lower rating may cause the appliance to overheat.
4. To reduce the risk of electric shock, do not disassemble the appliance. For repairs, contact our customer service team. Improper reassembly can result in electric shock.
5. Please do not use unrecommended accessories which may cause a risk of fire, electric shock, or injury to persons.



The VIVOHOM warranty program is our commitment to you. We are committed to providing you with a high-quality product that meets your needs and expectations. To demonstrate our confidence in the durability and performance of our products, we offer the following warranty.

WARRANTY COVERAGE

This warranty applies to all orders, purchases, or use of products sold only by VIVOHOM and is valid for 1 year from the purchase date. Please note, this warranty only covers the original order. If a replacement is provided within the warranty period, it does not extend the warranty.

WARRANTY EXCLUSIONS

This warranty does not cover damages caused by misuse, accidents, unauthorized modifications, or any factors unrelated to product manufacturing and design, including but not limited to:

- Loss of parts during use.
- Normal wear and tear of products or parts.
- Incorrect installation (e.g., using the wrong voltage) or improper assembly.
- Overloading the product's bearing capacity.
- Usage in extremely harsh conditions.
- Improper cleaning or lack of maintenance.
- Damage resulting from unintended use of the product.
- Damage resulting from unauthorized modifications or service.
- Indirect losses or damages related to the product.

HOW TO MAKE A WARRANTY CLAIM

If you encounter any defects affecting the product's functionality or if the product fails and cannot be repaired during the warranty period, please reach out to our customer service team via email, Amazon, or our app's messaging service at your earliest convenience. To expedite your claim, kindly include:

- Order number
- Photos and/or videos illustrating the issue
- A detailed description of the problem

VIVOHOM will provide technical support, replacement, refund, or other solutions based on the issue's specifics. If you wish to return the original package for any reason, please contact us for confirmation before initiating the return. You can expect a response within 48 hours.

Thank you for choosing VIVOHOM. We are dedicated to ensuring your satisfaction and the quality of your purchase. If you have any questions or need further assistance, please don't hesitate to reach out to our customer service team.