









ASSEMBLY INSTRUCTION

A x1 	B x1 	C x1 	D x1 
Backrest	Seat	Armrest-L	Armrest-R
E x1 	F x1 		
Power cord	Remote control		



ASSEMBLY INSTRUCTION



No.1 and No.2 wire connect with the backrest and chair base.



No.3 wire connects with backrest and power cord.

No.4 wire connects with backrest and remote control(F)


NOTE: Two same color wires connect.



4



How to use massage remote control?



- POWER : Turn on/off remote control.
- HEAT : Turn on/off heat function for lumbar part only.
- INTENSITY : Control massage function from low to high.
- MODE : Choose one massage mode you like(pulse, press,wave,auto, normal)
- You can choose 1-4 massage parts(back, lumbar, thighs, legs)to enjoy.
- TIMER:the default length is 30min,you can choose desired length of massage 15min,30min,60min.