

























ASSEMBLY INSTRUCTIONS

NO.: DK-240606-3


A1  X1	A2  X1	B1  X1	B2  X1
C1  X1	C2  X1	D  X2	E  X1
F  X3	G  X1	H  X1	I  X2
J  X2	K  X1	L  X2	M1  X4
N  X2	O  X2	P  X1	M2  X6
R  M6*18mm X28	S  M6*40mm X2	T  M6*16*1mm X2	Q  M6*25mm X8
U  M6 X1			




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11




STEP 12




STEP 13




STEP 14




STEP 15




STEP 16




STEP 17




STEP 18




STEP 19




STEP 20




STEP 21



STEP 22



STEP 23



STEP 24

