





Assembly Instruction




Components 




A x1pc




B x1pc




C x1pc




D x1pc



E x1pc



F x1pc



G x1pc



H x2pcs




I x2pcs




J x1pc




K x1pc




O x1pc



P x2pcs




Q x2pcs



R x1pc



T x2pcs



L x38pcs



M x8pcs



N x12pcs




S x38pcs




x1pc

1




 **L** x2pcs  **S** x2pcs

2




 **L** x4pcs  **S** x4pcs  **N** x4pcs

3




 **L** x4pcs  **S** x4pcs  **N** x2pcs

4




 **L** x8pcs  **S** x8pcs

5




- | | | |
|---|--|---|
|  L x10pcs |  N x4pcs |  S x10pcs |
|---|--|---|


6




7



8




9



M x8pcs







10



All done

TV Stand Tipover Kit

For use on all TV stand models



Wall anchor kit components



Additional items you may need for installing the wall anchor



- Note that the use of wall anchor kit may only reduce, but not eliminate the risk of tipover.
- Note for safe mounting, it is essential to use wall anchors appropriate to your wall type (e.g., drywall, brick, plaster).
- Note wall mount to wood studs whenever possible.
- Note for attaching to other specific wall types, or for additional wall fastener questions, please consult a qualified professional. Zinus instructions and provided hardware are meant for Hard brick or cement wall mounting.
- Note to periodically check that all fasteners are tight and free of damage, replace as necessary.

CAUTION This stand is intended for use with a product that has dimensions that will permit it to sit evenly on this stand (refer to instructions for details). Use with other products, including products that have dimensions larger than the maximum dimensions allowed, may result in instability and possible injury. This stand is intended for up to a 65" flat panel TV

⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER exceed the maximum size and weight of the TV shown in the instructions.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!