



INSTALLATION INSTRUCTION



NO.	PICTURE	SIZE	QTY
A		M6X35L	6
B		ST5X50L	18+2
C		ST5X40L	18+2
D			4
E			1
F		ST3.5X14L	2
G		700L	1
H			4
		ST4X50L	4
I		Ø3X2.5"	8
J			3
		ST3X12L	6
			1

ASSEMBLY INSTRUCTION

①



X1

②



X1

③



X1

④




X1

⑤



X2

⑥



X1

⑦



X1

⑧



X1

⑨



X1

⑩



X1

⑪



X2

⑫



X1


⑬



X1

INSTALLATION INSTRUCTION

STEP 1




C ST5X40L



X2

STEP 2




C ST5X40L




X8

INSTALLATION INSTRUCTION

STEP 3




STEP 4




INSTALLATION INSTRUCTION

STEP 5



B ST5X50L	A M6X35L
	
X4	X2


STEP 6



F ST3.5X14L	E
	
X2	X1


INSTALLATION INSTRUCTION

STEP 7



B ST5X50L	C ST5X40L
	
X4	X4

STEP 8





C ST5X40L


X4

INSTALLATION INSTRUCTION

STEP 9




STEP 10



INSTALLATION INSTRUCTION

STEP 11




H ST4X50L




X4

H



X4

STEP 12



I Ø3X2.5"



X8