



























TV STAND

Notice:

1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, refer to two solutions: Follow the installation video tutorial on the Amazon product page or contact our customer service.

Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
A		×44	G		×6
B		×44	H		×8
C	 Ø8×30	×24	I	 M4×25	×4
D		×4	J		×2
E	 M4×14	×48	K		×4
F		×8	-		-


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
1		×1	8		×2
2		×1	9		×2
3		×2	10		×2
4		×1	11		×1
5		×1	12		×1
6		×1	13		×1
7		×1	14		×1
			15		×2

1

M6×30




(B) 16PCS




(2) 1PCS



(5) 1PCS



(6) 1PCS




3


2




(A) 8PCS



(8) 2PCS





(9) 2PCS



4

3



5

4


M4×14



E 24PCS



G 6PCS




6

5




ⓕ 8PCS




6



Ⓑ 8PCS




⑪ 1PCS





⑫ 1PCS





⑬ 1PCS



⑭ 1PCS





7



9

8




10

9

(A) 8PCS

Ø8×30


(C) 8PCS



11



10

(A) 4PCS




12

11



13

12




14


13



④ 4PCS



⑦ 1PCS




15

14




⑧ 8PCS

∅8×30



⑨ 8PCS



16

15

M4×14




Ⓔ 8PCS

M4×25



Ⓘ 4PCS



⓵ 2PCS




Ⓚ 4PCS




Ⓜ 2PCS


Sets×2




17



Up / Down




Before / After




Left / Right


16



Adjust doors upwards/downwards well before tightening the screw marked green.



Adjust doors frontwards/backwards well before tightening the screw marked green .



Turn the screw marked green to adjust doors to the left/right well.


18

17


M4×14



ⓔ16PCS



18



WARNING: This product contains a chemical known to the State of California to cause cancer. This product contains a chemical known to the State of California to cause birth defects or other reproductive harm.
For more information go to www.P65Warnings.ca.gov

Installation Completed