

ASSEMBLY INSTRUCTION


PARTS



The upper front panel
(CT-0055-3) x 1



Upper back panel
(CT-0055-4) x 1



Upper side panel
(CT-0055-6) x 2




Pointed eaves
(CT-0055-14) x 1




Flat eaves
(CT-0055-15) x 1




Screw x 14




Food bowl
(CT-0055-12) x 1




The lower front panel
(CT-0055-7) x 1




Lower back panel
(CT-0055-8) x 1



Lower right panel
(CT-0055-9) x 1



Lower left panel
(CT-0055-10) x 1



Intermediate layer board
(CT-0055-5) x 1



Base plate
(CT-0055-11) x 1



Left Roof
(CT-0055-2) x 1




Right Roof
(CT-0055-1) x 1



Waterproof
strip x 1


•Please view above parts with number before asssemblying. In order to easy installation, each panel has marked with number, for example, back panel marked "(CT-0055-1)" at back side. If you have any questions about the assembly processing or quality issues, please feel freely to contact us, and we will reply you within 24 hours.

INSTRUCTION




1

First, clamp the bowl rack under the bottom left panel




2

Fix the left panel and the bowl rack to the base plate with screws



3

Fix the right side panel of the bottom layer to the base plate with screws, and then insert and fix the flat eaves




4

Fix the bottom front panel to the side panels and bottom panels with screws




5

Fix lower back panel to the side panels and bottom panels with screws




6

Align the middle board and press it firmly into the corresponding clips




7

Press the upper front panel down into the middle panel and insert the pointed eaves



8

Fix the left and right side panels to the front panel with screws and then press in the middle panel for fixation



9

Fix the back plate to the left and right side plates with screws and press it down into the middle side plate



10

Press the corresponding clips into the left and right roofs and insert the waterproof strip into the gap between the eaves



11

Put the water bowl and grain bowl into the bowl rack



12

Installation completed