



CUTTING PIXL PORCELAIN TILE

Wet saws are generally used when cutting tile. PIXL uses continuous rim diamond tip blades designed to cut porcelain tile and glass.

These blades have a softer rim that exposes a fresh diamond cutting edge when used on hard dense porcelain; also the diamonds are smaller and closer together providing a smoother cut and less chipping.

Best results have been when minimum but firm pressure is applied while pushing the tiles through.

Example:

- Felker TM-5 or the new Narrow-width TM-7
- MK-415 Super High Rim or the narrow MK-225 "Hot Dog"
- Rubi CPC 250 10"

If tiles crack or break during the cutting process, several factors could be the cause:

- Blade is old or worn out, bent or warped
- If the cutting head bearings are worn or loose, vibration can occur resulting in breakage.
- In some cases, dressing the blade with a dressing stone may prove helpful.

Information from MK Saws and Blades (ph: 800-845-3729) www.mkdiamond.com website

Or

Felker Saws and Blades (800-365-4003) www.felkersaws.com describes proper blade selection and common blade problems