



**COFFEE.
TEA.
SMILE.
REPEAT.**

CONTACT US

Email: support@sylviera.com
Tel: 2137969388
Web: <https://sylviera.com/>

Important Safeguards	02
Save These Instructions Household Use	
Only	03
Specifications	04
Package Contents	04
Know Your Kettle	05
Water Test	06
Boiling Water	07
Descaling the Kettle	08
Cleaning	09
General Safety	09
Warranty	10

Your purchase comes with a 100% satisfaction guarantee from Sylvira. Sylvira supports free replacement for any problems or full refund for dissatisfaction under warranty. We will take care of all quality-related issues with a replacement or full refund including any return shipping costs. If your product is defective and under warranty, please contact us at
Email: support@sylvira.com.

If you're happy with this kettle, the line doesn't stop here. Check out <https://sylviera.com/> for a line of all our beautiful and thoughtfully designed appliances. They might be right at home in your kitchen, too!

1. Read all Instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock and injury to persons do not immerse cord, plugs, or appliance in water or other liquid.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. To disconnect, turn any control to "off", then remove plug from wall outlet.

CAUTION: Risk of injury, any other servicing should be performed by an authorized service representative

How to Descale/Clean the Kettle?



3. Rinse the kettle with clean water, and dry with a soft, clean cloth. Repeat as needed.

Product name	Electric Kettle
Model	LD-K3041E
Capaciiy	1.8qt(1.7L)
Rated Power	1500W
Power Supply	AC120V,60Hz
Jug material	304 stainless steel

- 1 x Stainless Steel Kettle
- 1 x Power Base
- 1 x User Manual
- 1 x Quick Start Guide

A diagram of a red electric kettle with the following labeled parts:

- A**: Lid
- B**: Spout
- C**: Handle
- D**: Power cord
- E**: Base
- F**: Water level indicator

- A. Lid
- B. Lid Release Button
- C. Handle
- D. Indicator Light(On/Off Switch)
- E. Power Base
- F. Spout

Allow it to cool for at least 5 minutes, then pour out the water.



Figure 1.3