
ECOSELF

USER MANUAL

HAP-603
True HEPA Air Purifier



PLEASE KEEP THIS MANUAL CAREFULLY FOR FUTURE REFERENCE.
FOR HOUSEHOLD USE ONLY.

REGISTER NOW!

for an additonal **12** months Warranty

As a special thank-you for registering your ECOSELF unit, you'll automatically receive an additional 12 months added to your limited manufacturer's warranty!

All you need to do is send your order ID to our Email: support@myecoself.com, or enter your order ID to activate the extended warranty online at www.myecoself.com/?vipwarranty.

This warranty only cover orders from authorized brand online stores and our official website. We are not responsible for any purchases from other distribution channels.

- Any questions, please REACH OUT to ECOSELF before returning it, as we provide hassle-free after-sales support.
- FREE upgrade to FULL Replacement Guarantee - no need to return.
- Once registered, you will be ensured that if anything goes wrong with your product, we will either send you a brand new unit as a replacement (Absolutely FREE) or provide a FULL refund of your order.
- Just send your Amazon Order ID to Email support@myecoself.com or scan the OR code to activate the extended warranty.

Send: support@myecoself.com

Subject: Warranty

Order ID:

TABLE OF CONTENTS

General Safety 01

Product Map 03

Controls & Display 04

What's in The Box 05

Getting Started 05

Using Your Smart Air Purifier 07

About The Filter 09

Care & Maintenance 10

Specifications 11

Troubleshooting 12

Warranty 13


General Safety


- ECOSELF HAP-603WF Air Purifier is an electrical appliance for indoor use only.
- Take the necessary precautions to reduce the risk of fire, electric shock or injury.
- **READ AND SAVE THESE INSTRUCTIONS.**
- **WARNING:** To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Air Purifier With Any Solid-State Speed Control Device.
- Only use your air purifier as described in this manual.
- Do not use without removing the plastic wrap from the filter. The air purifier will not filter air and may overheat, causing a fire hazard.
- Keep your air purifier away from water and wet or damp areas. Never place it in water or liquid.
- Do not use in excessively humid areas.
- Keep your air purifier away from heat sources.
- Do not use where combustible gases, vapors, metallic dust, aerosol (spray) products, or fumes from industrial oil are present.
- Keep 5 ft / 1.5 m away from where oxygen is being administered.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Do not allow children to play with the plastic packaging. Immediately discard the plastic after unwrapping the filter.
- Do not place anything into any opening on the air purifier.
- Do not sit or place heavy objects on the air purifier.
- Keep the inside of the air purifier dry. To prevent moisture buildup, avoid placing it in rooms with major temperature changes.
- Always unplug your air purifier before servicing (such as changing the filter).
- Do not use your air purifier if it is damaged or not working correctly, or if the cord or plug is damaged. Do not try to repair it yourself.

- Children should not clean or perform maintenance on the air purifier without supervision.
- Keep the appliance, including the power cable, at a safe distance from heated surfaces and open fire.
- Never clean with gasoline, chemical solvents, or corrosive materials as these agents may damage the air purifier.
- Never place the cord near any heat source.
- Do not cover the cord with a rug, carpet, or other covering. Do not place the cord under furniture or appliances.
- Keep the cord out of areas where people walk often. Place the cord where it will not be tripped over.
- This air purifier is only to be used with the power supply adapter provided with the air purifier.

Product Map

A. Change Filter Indicator
B. Timer Indicators
C. Child Lock Indicator
D. Power On/Off Indicator
E. Fan Speed Indicators
F. Auto Mode Indicator
G. Light Off/On Indicator
H. Filter Reset Button
I. Timer Button
J. Child Lock Button
K. Power On/Off Button
L. Fan Speed Button
M. Auto Mode Button
N. Light Off/On Button
O. Housing
P. Power Adapter
Q. 3 Stage Filter
R. Filter Cove





Controls & Display

	**On/Off Button** • Turns the air purifier on/off.
1F 2F 3F 	**Fan Speed Button & Indicators** • Cycles through fan speeds: low (1F), medium (2F), high (3F), and sleep ( ).
	**Auto Mode Button** • Turns Auto Mode on/off.
	**Timer Button** • Set the timer for 2 hours, 5 hours, or 8 hours. **Note:** The timer indicators will light up with the corresponding timer selected. To cancel the timer, tap until all timer indicators are off.
	**Change Filter Indicator & Reset Button** • Lights up when the filter needs to be changed. • To reset the Filter Life (after changing the filter), press and hold the button for 5 seconds. Device will beep 3 times and then turn off.
	**Light Off/On Button** • Turns the Air Quality Lights off. • When lights off, tap to turn back on.
	**Child Lock Button** • Prevents current settings from being changed. Press and hold for 3 seconds to lock and unlock the Control Panel. • When the Control Panel is locked, the Child Lock button will light up and beep twice when any other button is tapped to indicate the display is locked.
	Air Quality Indicator • Display the air quality using an automatic infrared dust sensor: Green(Very Good), Orange (Moderate), Red (Bad).
	**Display** • Display the Fan Speed, PM 2.5 levels, Filter Life.

What' s in The Box

1x Air Purifier

1x Adapter (In the bottom or Air Purifier)


1x 3-Stage Filter (Pre-installed, protected by plastic wrap, it must be removed before first use.)

1x User Manual


Getting Started


1. Place the air purifier on a flat, stable surface such as the floor.

2. Pull both sides of the filter cover to remove it.




3. Remove the Filter (protected by plastic packaging) from inside the air purifier.






4. Remove the plastic packaging from the filter and place the filter back into the air purifier.




Note: Be sure to remove the filter packaging before use. Otherwise the air purifier will not filter the air and may overheat, causing a fire hazard.
Make sure the side marked with "**FRONT**" is facing outward when you insert the filter.

5. Replace the filter cover. Make sure to align the tabs on the cover with the slots on the bottom of the air purifier.



6. Insert the power adapter plug into the side of the air purifier.
Note: The power adapter is located underneath the air purifier.



Using Your Smart Air Purifier

1. Plug in and tap to turn on the air purifier. The air purifier will start on low(1F) speed by default.
2. Tap to change fan speed between low (1F), medium (2F), high (3F), and sleep ( ).

Note:
- High fan speed (3F) is the loudest, but cleans air the quickest.
- For best results, or to address a specific air quality issue such as smoke, run the air purifier on High fan speed for 15–20 minutes before using a lower speed.
- To effectively clean air, keep windows and doors closed while the air purifier is on.

Sleep Mode

Sleep Mode operates quietly by using a fan speed lower than speed 1F.
1.Tap to switch to Sleep Mode (indicator lights up).
2.Sleep Mode will turn off the display except (semi bright) after 5 seconds if no other buttons are tapped.

Note:
- When the display is turned off, tap any button to turn the display back on. If you don't tap another button, the display will turn off again after 5 seconds.

Auto Mode

Auto Mode uses an infrared dust sensor inside the air purifier, to adjust the fan speed automatically based on air quality. For example, if the air quality is bad, the fan will automatically be set to high speed.

1. Tap to turn Auto Mode on.
2. The Auto mode indicator will light up while Auto Mode is active.
3. To switch from Auto Mode, tap to select a fan speed.

Air Quality Indicator Chart		
Light Color	**Air Quality**	**Auto Mode Fan Speed**
Green	Very Good	1F
Orange	Moderate	2F
Red	Bad	3F

Timer

1. You can manually set the timer for 2 hours, 5 hours, or 8 hours.
2. Once the timer has finished, the air purifier will turn off.
3. To cancel the timer, tap ⏲ until all timer indicators are off.

Note:
• You can change the fan speed at any time while the timer is on.
• The timer will restart if the time is changed.

Light Off/On


This turns off the air quality indicator on the air purifier

• Tap ☼ to turn off the air quality lights.
• Tap ☼ to turn the air quality lights back on.

Standby Mode

The air purifier is in Standby Mode when it is turned off, but plugged in.

Aromatherapy Function




1. Remove the covers at both ends. Open the top cover of the essential oil box.
Add your chosen essential oil (4-5 drops each time). Reassemble the parts.
2. Put it back in the slot. (Fit for a Machine with a grille.)

Note:
Turn off the machine before adding oils.
Use provided droppers: don't pour directly. Add 4-5 drops each time.

About The Filter

The air purifier uses a 3-stage filtration system (3 in 1) to purify air.



A. Pre-Filter

• Captures large particles such as dust, lint, fibers, hair, and pet fur.
• Maximizes the filter's life by protecting it.

B. True HEPA Filter

• Filters small particles such as fine dust, smoke particles, and allergens such as pollen and pet dander.

C. Activated Carbon Filter

• Helps captures and neutralizes cooking smell, smoke, odors, fumes and VOCs.

Care & Maintenance

Cleaning the Air Purifier

• Unplug before cleaning.
• Wipe the outside of the air purifier with a soft, dry cloth. If necessary, wipe the housing with a damp cloth, then immediately dry.
• Vacuum the inside of the air purifier.
• Do not clean with abrasive chemicals or flammable cleaning agents.

Cleaning the Pre-Filter

• The outer Pre-Filter should be cleaned every 2–4 weeks to increase efficiency and extend the life of your filter. Clean the pre-filter using a soft brush or vacuum hose to remove hair, dust, and large particles.

Note:
• Do not clean the filter with water or other liquids.
• Do not clean the True HEPA and Activated Carbon Filters.
• Moisture may damage the filter. This air purifier should be used in an area with a humidity level below 85% RH. If you use the air purifier in excessively humid areas, the surface of the filter will become moldy.
• Do not add essential oils to the air purifier or filter The filter will become damaged by the oil and will eventually release an unpleasant smell.
• Do not use oil diffusers near the air purifier.

Replacing the Filter

1. Unplug the air purifier, then pull the front cover to remove it (see Getting Started 2.).
2. Remove the old filter from the air purifier.
3. Clean out any remaining dust or hair inside the air purifier using a vacuum hose.

Note: Do not use water or liquids to clean the air purifier.

4. Remove the plastic packaging from the new filter and place the filter inside the air purifier (see **Getting Started** 4.)

Note: Make sure the filter (the side marked with "**FRONT**") is facing outward when you insert the filter.

5. Replace the filter cover.
6. Plug in and turn on the air purifier. Reset the Filter Life.
To reset the Filter Life, press and hold  for 5 seconds. The Indicator will flash and beep for 2 times, and turn off.

Storage

If not using the air purifier for an extended period of time, wrap both the air purifier and the filter in plastic packaging and store in a dry place to avoid moisture damage.

Specifications

Model	HAP-603
Power Supply (Input)	AC100-240V, 50/60Hz
Power Supply (Output)	DC24V, 1.0A
Dimensions	310*160*400mm
Weight	3.2 KG

Troubleshooting

Problem	Reasons	Possible Solutions
Air purifier cannot be turned on or no respond to button controls.	No electricity.	Check that the unit is properly plugged into an electrical outlet.
	The air purifier malfunctioned.	Contact ECOSELF: **support@myecoself.com**
	Power cord is damaged.	
	The outlet is damaged.	Try a different outlet.
Airflow is significantly reduced.	The airflow is blocked by plastic wrap of filter. **Note:** Air filter was pre-installed protected by plastic wrap.	The plastic wrap of filter mustbe removed before first use.
	There is no enough clearance for the air comes in.	(1)Leave 12inch / 30cm clearance on all sides of the air purifier. (2)Keep air purifier away from anything that would block airflow, such as curtains.
	The Pre-filter maybe clogged by large particles so that the airflow is blocked.	Clean the Pre-filter or replace the filter. Refer to **Care & Maintenance**.
Air purifier makes an unusual noise while the fan is on.	The airflow is blocked by plastic wrap of filter.	The plastic wrap of filter must be removed before first use.
	Appliance is on uneven place.	Make sure the air purifier is operating on a hard, flat, even surface.
	Appliance may be damaged, or foreign object inside.	Contact ECOSELF: **support@myecoself.com**
Strange smell comes from the purifier.	T It is time to clean/replace the filter.	Clean the filter or replace it.
	Appliance worked in an area with a humidity level above 85% RH. The surface of the filter will become moldy.	(1)This air purifier should be used in an area with a humidity level below 85% RH. (2)Replace your filter.
Poor air purification quality	A low speed is used when air is in the high pollution.	Increase the fan speed / switch to AUTO mode.
	(1)The airflow is blocked by plastic wrap of filter. (2)The airflow of inlet/outlet is blocked.	(1)The plastic wrap of filter must be removed before first use. (2)Make sure no objects are blocking the front or top of the air purifier (the inlet or outlet).
	Windows or doors not closed.	Keep windows and doors closed while the air purifier is on.

Air purifier always detects high levels of particulates	The unit is operating in a very dusty environment.	Consider turning the fan speed to HIGH / switch to AUTO mode.
is still on after replacing the filter.	Forget to reset the air purifier.	Long press the button for 5 seconds to reset the filter life.
has not turned on after 9 months.	The appliance is run infrequently or the air is in the high quality so that it takes longer to inform you.	The indicator will turn on based on how much the air purifier has been used. If you don't use your air purifier often, it will take longer to turn on.
turned on before 6 months.	The appliance is run frequently or the air is in the high pollution so that it takes shorter to inform you.	Replace the filters.

Warranty

We are delighted that you have chosen the ECOSELF air purifier and hope you have a fun with it. The manufacturer's warranty covers the product for a period of 12 months from the date of purchase against manufacturing faults.

If you have any questions about the device and about spare parts/accessories, contact the customer service department via:

support@myecoself.com

www.myecoself.com

facebook.com/Ecoself.Official

1-888-610-8877 (M-F 9:00-17:00 EST)

Through the following channels,
you can quickly contact us.


support@myecoself.com


www.myecoself.com


facebook.com/Ecoself.Official


1-888-610-8877 (M-F 9:00-17:00 EST)