

Shopify





amazon

Manual Version: 1.1.1

Newacme LLC, 2808 Vail Ave, Commerce, CA, 90040 sales@mcombo.com 1-323-597-1109 (8:00 a.m. - 4:00 p.m. (Monday - Friday) TIME ZONE: PST)

NEWACMELLC www.mcombo.com / sales@mcombo.com

OWNER'S MANUAL **MOTORIZED AWNING**

6055-4693



MCombo®, with the mission of "bringing more convenience to family and travel life", the vision of "becoming the first choice and trusted brand of customers in outdoor series", and the core value of "providing high-quality and high-standard outdoor products", awakens people pay attention to the outdoor garden life itself, extend the time to play with family and partners in the outdoor garden, and enjoy a healthier and more comfortable life.

This user manual is for 6055-4693. MCombo reserves the right to change, update any content contained herein without prior notice.

Please read, understand, and follow this user manual before assembling and using. Save this manual for future reference. It's the responsibility of the user for potential risks of injuries due to inappropriate use not obeying safety instructions in this manual.

| I. Safely Guidelines |
|------------------------------------|
| II. Preparation |
| III. Part List |
| IV. Parts Exploded View |
| V. Assembly Steps |
| VI. About the Motor |
| VII. Return / Replacement Policy - |
| VIII. MCombo Customer Support |
| IX. Warranty Disclaimer |
| |

o Purchaser's Agreement

By accepting delivery of this product, you promise that you will not change, alter, or modify this product or remove or render inoperable or unsafe any guards, shields or other safety features of this product.

You will not refuse or neglect any retrofit kits that MCombo may provide to enhance and preserve the safe use of this product.

MCombo[®]

Table of Contents

| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 03 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|----|
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 04 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 05 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 07 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 08 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 16 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 18 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 19 |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 20 |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

I. Safely Guidelines



For your own safety, please strictly follow the instructions in this manual, otherwise personal injury may result!

Before you proceed, please read the following safety precautions:

- Due to the strong elasticity of the umbrella arms, please tie the umbrella arms together when assembling the umbrella arms. Do not stand facing the front of the awning when cutting the strap between the arms. Hold on tight and slowly stretch until fully open.
- The product is bulky and heavy, requiring two adults to carry and install it. Please use all screws and nuts correctly during installation, it is very dangerous if loosened.
- Do not place, hang or stand objects or people on the awning.

Doing so may damage the awning or cause serious personal injury, even death in extreme cases.

• Do not install it in a high place, a windy place, a place with vibration or impulse, and a high-temperature place such as a wall near the furnace.

Never use it for any purpose other than that suggested. Be careful with your fingers when installing.

• Do not open the awning under the following circumstances:










II. Preparation

• Before you start, check the condition and quantity of all parts according to the parts list.




• Please prepare all the necessary tools.




Determine where to install your Awning?


• Reference Location:




MCombo®

III. Part List






IV. Parts Exploded View



V. Assembly Steps




Fix left & right Torsion Bar with Arm (#A-1,#A-2) by Screws (#D).





Connect left with right Roller (**#B-1,#B-2**) by Screws (**#J**).




| | 3 | Connect left with right Front Bar (#C-1,#C-2) by Screws | s (#J). |
|-------------------|---|--|------------------|
| C-1 C-1 C-2 | | C -1 | |




Install the Fabric.

ends of Roller and Front Bar.



Thread three Guiding Wires (#N) through both ends of the large Fabric (#M) and




MCombo®

Pg / 10

round Roller and Front Bar. Cutting off excess threads.




Put together rolled Roller from **step 5** with Torsion Bar from **step 1**.





Slide the Arm Link (#F) into each end of Front Bar, then insert (#F) into holes in Torsion Bar.
Note: (1). If it is not good to slide in, you can loosen the two short screws a little.
(2). Please tighten screws at the bottom of (#F).






Connect Roller with Torsion Bar.


(1). Sleeve Left & Right Roller Support (**#E-1**, **#E-2**) with two ends of Roller and Torsion Bar.

(2). Fix (**#E-1**,**#E-2**) with Torsion Bar by Screws (**#E-3**).






Thread (**#O**) with (**#N**) through the other slot of Front Bar.



MCombo

MCombo°






Mounting on the Wall:


hole that should not be less than 4 inches.

Bolts(#I-1) / Wood Screw (#I-2).

Measure the total length of the canopy "Length". Divide the total length roughly into four segments (find three points).



(#H), lock the screws and tighten the nuts.



MCombo®


MCombo




Use of Awning.



Adjusting Motor Travel






According to motor rotating direction, adjust the travel limit with the use of the 4mm hex wrench #Q-1.

Tips: The direction of " + " is increasing the travel limit and " - " is to reduce the travel limit.

After setting, open and close the awning with the remote control and check if the setting is satisfactory. If not, repeat step 3.

VI. About the Motor


1. Remote Control



MCombo


Tips: Insert the plug of the motor into the socket (rated voltage 110V) and pull out the toggle on the back cover of the remote control to turn on the power supply.

2. Re-initialization of the Remote Control



Tips: The motor and remote control are already coded and connected at the factory setting.

If the motor does not respond when you operate the remote control, you can re-code it as follows.



Repeat the above steps, except press the "DOWN" button for the set up of extraction.

ATTENTION

The motor's automatic protection function may be triggered by frequent operation, we recommend waiting 20 minutes before re-energizing for optimal performance.

VII. Return / Replacement Policy

| Notice | |
|--------|--|
| NOLICE | |

Why don't we recommend returning the item by yourself?

- Huge cost- UPS/FedEx oversize fee.
- Need you to take the box to UPS/FedEx facility.

We stand behind our products and want you to be satisfied with them. We'll always do our best to take care of customers, and that's why we offer a straightforward, hassle-free return policy.

Return Process

You have 30 days from the date of purchase to return any item purchased from our store. Please securely pack the item in its original packaging, including any accessories or manuals that came with the product. To initiate a return, please contact our customer service team at (sales@mcombo.com / 1-323-597-1109) for any help.

Return Conditions

We accept the return of items that are in new, unused condition, with original tags attached and all original packaging and other components included. Refunds will be issued in the original form of payment for the price of the item, including taxes.