
Patio Conversation Set



Model:2616

Scan the QR code to learn more about our product.

WARNINGS

Not for Children
This sofa set is intended for adult use only. Avoid allowing children to play or climb on the furniture to reduce the risk of injury.
No Standing on Furniture
The furniture is designed for sitting only. Do not stand, jump, or place excessive weight on the armrests or backrests.
Avoid Modifications
Do not modify or attempt to repair the sofa set. Contact customer service for any necessary repairs or replacement parts.

Important Safety Information

Choking Hazard: Keep packaging materials, small parts, and screws away from children. This product contains parts that could be harmful if swallowed.
Adult Supervision: Always supervise children around the furniture, especially when playing or climbing.
Stable Surface: For safety and stability, ensure the sofa set is placed on a level, stable surface. Avoid placing it on uneven or slippery ground.
Weight Limit: Please do not exceed the recommended weight capacity for each seating unit and coffee table to prevent damage. Refer to the product's weight specifications for more details.
Cushion Safety: Ensure that cushions and pillows are securely in place before using the furniture. Avoid using the product if any cushions are damaged or misplaced.
Protect from Weather: Although the rattan material is designed for outdoor use, we recommend covering the sofa set or moving it to a sheltered area during heavy rain, snow, or extreme sunlight exposure to protect the cushions and prolong the life of the set.
Proper Assembly: Always ensure that all components are properly assembled and that all screws and bolts are tightened securely before use. Check for loose screws periodically.

CONTENTS

Warnings.....1

Packing List.....4

Assembly steps for middle sofa.....9

Assembly steps for corner sofa.....12

Assembly steps for coffee table.....14

U-shapped connector.....17

Sofa cover washing instruction.....18

Maintenance and Care.....18

CONTACT US

If you have any questions or concerns regarding our product, please don't hesitate to contact our customer service team at [service@outsofas.com]. We are committed to providing excellent service and ensuring your satisfaction.


Scan The Qr Code And Click The Chat Button To Contact us.

Web:www.outsofas.com

E-mail:service@outsofas.com


List of Parts in Box A

A1 × 1




Left Armrest

A2 × 1




Right Armrest

B5 × 1




Corner Long Backrest

D × 1




Sofa Side Panel

H × 1




Coffee Table Top

E × 3




Long Back Cushion

F × 1




Short Back Cushion

K × 6




Universal Panel for Sofa Base

L × 4




Panel for Armrest Sofa Base

M × 2




Panel for Corner Sofa Base

N × 2




Panel for
Middle Sofa Base

W1 × 2




Long Panel for
Coffee Table Base

W2 × 2



Short Panel for
Coffee Table Base


U × 6



U-Shaped Connector


List of Parts in Box B

C1 × 2




Sofa Seat Plate

C2 × 1




Right Armrest
Sofa Seat Plate

B2 × 1




Right Armrest
Sofa Back Plate

B1 × 1




Left Armrest Sofa Back Plate

B4 × 1




Corner Sofa Back Plate

G × 3




Seat Cushion

I × 2











Long Side Panel
of Coffee Table

J × 2






Short Side Panel
of Coffee Table

List of Parts in Box C




C1 × 2  Sofa Seat Plate	B3 × 2  Middle Sofa Back Plate	D × 2  Sofa Side Panel
E × 2  Long Back Cushion	G × 2  Seat Cushion	N × 4  Panel for Middle Sofa Base
K × 4  Universal Panel for Sofa Base	U × 2  U-Shaped Connector	

Screw Set(B)






Corner Sofa's Screw × 1

S × 7	T × 16	O × 16	P × 8
			
Bolt M6×35	Bolt M6×50	Washer Nut	Adjustable Screws

Armrest Sofa's Screw × 2




S × 4	T × 16	O × 16	P × 8
			
Bolt M6×35	Bolt M6×50	Washer Nut	Adjustable Screws

MIddle Sofa's Screw × 2



S × 7	T × 12	O × 12	P × 8	R × 4
				
Bolt M6×35	Bolt M6×50	Washer Nut	Adjustable Screws	Aperture Cover


Screw Set(C)

Coffee Table's Screw × 1




S × 16	T × 8	O × 8	P × 8
			
Bolt M6×35	Bolt M6×50	Washer Nut	Adjustable Screws

Additional Screw × 1

S × 4 Bolt M6×35	T × 5 Bolt M6×50	O × 5 Washer Nut
		


P × 4 Adjustable Screws	Q × 1 Restoration of rattan
	




General Installation Tool × 1

X × 2	Y × 2	Z × 2
		
Spanner	Wrench	Ratcheting Spanner

Step 1


Place the middle sofa seat plate (C1) onto the middle sofa backrest (B3) as shown in the diagram. Align the holes and secure with bolts (T) and nuts (O).
Note: Do not tighten fully; only hand-tighten enough to prevent slipping.





C1 × 1	B3 × 1	T × 3	O × 3	General Tools
		 Bolt M6×50		

Step 2


As shown in the figure, install the sofa side panel (D) between the seat panel (C1) and the back panel (B3) by aligning the holes, and secure it with bolts (S), bolts (T) and nuts (O).
Note: Tighten the bolts just enough to prevent looseness; do not fully tighten them.






D × 1	S × 3	T × 1	O × 1	General Tools
	 Bolt M6×35	 Bolt M6×50		

Step 3


Install the middle chair bottom frame (N) to the lower side of the middle chair backrest according to the diagram, and fasten it with bolts (T) and nuts (O).
Note: Do not fully tighten the screws. Just fasten them until they are not loose. Pay attention to the installation direction of the bottom frame. The side with screw holes should face inward during installation.






N × 1	T × 2	O × 2	General Tools
	 Bolt M6×50		

Step 4


Install the other piece (N) on the opposite side in the same way.
Note: Do not fully tighten the screws. Just fasten them until they are not loose. Pay attention to the installation direction of the bottom frame. The side with screw holes should face inward during installation.






N × 1	T × 2	O × 2	General Tools
	 Bolt M6×50		

Step 5


Install the universal bottom frames (K) on both sides in the same way, and fasten them with bolts (T) and nuts (O).
Note: Do not fully tighten the bolts. Only fasten them until they are not loose.




K × 1	T × 2	O × 2	General Tools
	 Bolt M6×50		

Step 6


As shown in the diagram, insert bolts (S) through the through holes on both sides of the bottom frame (K), and screw them into the inward-facing screw holes of the bottom frames (N) on both sides.
Note: Do not tighten them first; just screw them in place.




S × 2	General Tools
 Bolt M6×35	

Step 7


Install the other universal bottom frame following the same steps.
Note: After screwing in the bolts this time, you may use a ratchet wrench and an open-end wrench to tighten all screws completely.




 K × 1	S × 2  Bolt M6×35	T × 2  Bolt M6×50	O × 2 	General Tools 


Step 8



Screw the 8 adjustable feet (P) into the 8 holes on the bottom frame and tighten them securely.



P × 8 


Step 9	Each sofa seat panel is equipped with Velcro, and the bottom of the seat cushion (G) also has Velcro. Align the Velcro to secure the seat cushion. After placing the long back cushion (E), use the tying straps to fix the back cushion to the sofa back panel. **Note:** For a better appearance, the side with the zipper should generally face inward. **Install the other Middle Sofa using the same steps as above.**



E × 1 	G × 1 

Step 1


Place the middle sofa seat plate (C2) onto the Right armrest sofa backrest (B2) as shown in the diagram. Align the holes and secure with bolts (T) and nuts (O).
Note: Do not tighten fully; only hand-tighten enough to prevent slipping.



C2 × 1	B2 × 1	T × 3 Bolt M6×50	O × 3	General Tools

Step 2


As shown in the figure, align the right armrest (A2) with the holes and install it on the side of the seat panel and back panel with pre-drilled holes. Secure it with bolts (T) and nuts (O).
Note: Tighten just enough to prevent looseness; do not fully tighten.






A2 × 1	T × 5 Bolt M6×50	O × 5	General Tools

Step 3


Install the armrest sofa bottom frame (L) into the holes under the right armrest seat panel and backrest, and secure it with bolts (T) and nuts (O).
Note: Tighten the bolts into the nuts just enough to avoid looseness; do not fully tighten.One side of the bottom frame (L) has threaded holes, and the side with threaded holes should face inward.






 L × 2	T × 4  Bolt M6×50	O × 4 	General Tools 

Step 4


As shown in the figure, align the universal sofa bottom frame (K) with the holes on both sides and secure it with bolts (T) and nuts (O).
Note: Do not tighten.




 K × 2	T × 4  Bolt M6×50	O × 4 	General Tools 

Step 5

As shown in the diagram, insert bolts (S) through the through holes on both sides of the bottom frame (K), and screw them into the inward-facing screw holes of the bottom frames (L) on both sides.
Note: After screwing in the bolts this time, you may use a ratchet wrench and an open-end wrench to tighten all screws completely.




S × 4



Bolt M6×35


General Tools






Step 6

Screw the 8 adjustable feet (P) into the 8 holes on the bottom frame and tighten them securely.




P × 8





Step 7

Each sofa seat panel is equipped with Velcro, and the bottom of the seat cushion (G) also has Velcro. Align the Velcro to secure the seat cushion. After placing the long back cushion (E), use the tying straps to fix the back cushion to the sofa back panel.

Note: For a better appearance, the side with the zipper should generally face inward.




E × 1 


G × 1 


Step 1


Place the middle sofa seat plate (C1) onto the Left armrest sofa backrest (B1) as shown in the diagram. Align the holes and secure with bolts (T) and nuts (O).

Note: Do not tighten fully; only hand-tighten enough to prevent slipping.




 C1 × 1

B1 × 1 


T × 3  Bolt M6×50




O × 3 

General Tools 

Step 2


As shown in the figure, align the right armrest (A1) with the holes and install it on the side of the seat panel and back panel with pre-drilled holes. Secure it with bolts (T) and nuts (O).
Note: Tighten just enough to prevent looseness; do not fully tighten.






A1 × 1	T × 5	O × 5	General Tools
	 Bolt M6×50		

Step 3


Install the armrest sofa bottom frame (L) into the holes under the right armrest seat panel and backrest, and secure it with bolts (T) and nuts (O).
Note: Tighten the bolts into the nuts just enough to avoid looseness; do not fully tighten.One side of the bottom frame (L) has threaded holes, and the side with threaded holes should face inward.





L × 2	T × 4	O × 4	General Tools
	 Bolt M6×50		

Step 4

As shown in the figure, align the universal sofa bottom frame (K) with the holes on both sides and secure it with bolts (T) and nuts (O).
Note: Do not tighten.








K × 2

T × 4



Bolt M6×50

O × 4




General Tools






Step 5

As shown in the diagram, insert bolts (S) through the through holes on both sides of the bottom frame (K), and screw them into the inward-facing screw holes of the bottom frames (L) on both sides.
Note: After screwing in the bolts this time, you may use a ratchet wrench and an open-end wrench to tighten all screws completely.



S × 4



Bolt M6×35


General Tools






Step 6

Screw the 8 adjustable feet (P) into the 8 holes on the bottom frame and tighten them securely.




P × 8




Step 7

Each sofa seat panel is equipped with Velcro, and the bottom of the seat cushion (G) also has Velcro. Align the Velcro to secure the seat cushion. After placing the long back cushion (E), use the tying straps to fix the back cushion to the sofa back panel.


Note: For a better appearance, the side with the zipper should generally face inward.



E × 1



G × 1




We have included an extra sofa side panel (D) and two middle sofa bottom frames (N) as complimentary parts in the set.

If you want to assemble the set as shown in the diagram, you will need to install the corner sofa. I will now explain the installation steps for the corner sofa.


If you prefer a middle-position sofa, please turn to page 25.



Note: After installing the corner sofa, you will have one extra sofa side panel (D), two middle sofa bottom frames (N), and some extra screws left over. Please keep them properly and do not discard them. If you need to convert the corner sofa back to a middle sofa, you only need to disassemble some parts and reinstall them.



Step 1


Place the middle sofa seat plate (C1) onto the middle sofa backrest (B4) as shown in the diagram. Align the holes and secure with bolts (T) and nuts (O).
Note: Do not tighten fully; only hand-tighten enough to prevent slipping.






C1 × 1	B4 × 1	T × 3	O × 3	General Tools
		 Bolt M6×50		 

Step 2


As shown in the figure, align the Corner Backrest (B5) with the holes and install it on the side of the seat panel and back panel with pre-drilled holes. Secure it with bolts (T) and nuts (O).
Note: Tighten just enough to prevent looseness; do not fully tighten.






B5 × 1 	T × 5  Bolt M6×50	O × 5 	General Tools 

Step 3


Install the corner sofa bottom frame (M) into the holes under the seat panel and backrest, and secure it with bolts (T) and nuts (O).
Note: Tighten the bolts into the nuts just enough to avoid looseness; do not fully tighten.One side of the bottom frame (L) has threaded holes, and the side with threaded holes should face inward.




 M × 2	T × 4  Bolt M6×50	O × 4 	General Tools 

Step 4


As shown in the figure, align the universal sofa bottom frame (K) with the holes on both sides and secure it with bolts (T) and nuts (O).
Note: Do not tighten.





K × 2

T × 4




Bolt M6×50

O × 4




General Tools




Step 5

As shown in the diagram, insert bolts (S) through the through holes on both sides of the bottom frame (K), and screw them into the inward-facing screw holes of the bottom frames (M) on both sides.
Note: After screwing in the bolts this time, you may use a ratchet wrench and an open-end wrench to tighten all screws completely.




S × 4




Bolt M6×35

General Tools




Step 6

Screw the 8 adjustable feet (P) into the 8 holes on the bottom frame and tighten them securely.




P × 8




Step 7

Each sofa seat panel is equipped with Velcro, and the bottom of the seat cushion (G) also has Velcro. Align the Velcro to secure the seat cushion. After placing the long back cushion (E) and short back cushion (F), use the tying straps to fix the back cushion to the sofa back panel.


Note: For a better appearance, the side with the zipper should generally face inward.




E × 1



F × 1



G × 1




We have included an extra sofa side panel (D) and two middle sofa bottom frames (N) as complimentary parts in this set.

If you need to assemble the complete sofa set as shown in the diagram, please install the middle sofa. I will now explain the installation steps for the middle sofa.

If you prefer to assemble the corner-position sofa, please turn to page 21.


Note: When installing the middle-position sofa, you will have leftover parts: one corner backrest (B5) and two corner bottom frames (M). Please keep any extra screws properly. If you need to switch back to the corner sofa, you only need to disassemble and reinstall it.







Step 1

Place the middle sofa seat plate (C1) onto the middle sofa backrest (B4) as shown in the diagram. Align the holes and secure with bolts (T) and nuts (O).


Note: Do not tighten fully; only hand-tighten enough to prevent slipping.





C1 × 1	B4 × 1	T × 3	O × 3	General Tools
		 Bolt M6×50		

Step 2


As shown in the figure, install the sofa side panel (D) between the seat panel (C1) and the back panel (B4) by aligning the holes, and secure it with bolts (S), bolts (T) and nuts (O).
Note: Tighten the bolts just enough to prevent looseness; do not fully tighten them.





D × 1	S × 3	T × 1	O × 1	General Tools
	 Bolt M6×35	 Bolt M6×50		

Step 3


Install the middle chair bottom frame (N) to the lower side of the middle chair backrest according to the diagram, and fasten it with bolts (T) and nuts (O).
Note: Do not fully tighten the screws. Just fasten them until they are not loose. Pay attention to the installation direction of the bottom frame. The side with screw holes should face inward during installation.






N × 2	T × 4	O × 4	General Tools
	 Bolt M6×50		

Step 4


As shown in the figure, align the universal sofa bottom frame (K) with the holes on both sides and secure it with bolts (T) and nuts (O).
Note: Do not tighten.





K × 2	T × 4	O × 4	General Tools
	 Bolt M6×50		

Step 5


As shown in the diagram, insert bolts (S) through the through holes on both sides of the bottom frame (K), and screw them into the inward-facing screw holes of the bottom frames (N) on both sides.
Note: After screwing in the bolts this time, you may use a ratchet wrench and an open-end wrench to tighten all screws completely.




S × 4	General Tools
 Bolt M6×35	

Step 6

Screw the 8 adjustable feet (P) into the 8 holes on the bottom frame and tighten them securely.




P × 8




Step 7

Each sofa seat panel is equipped with Velcro, and the bottom of the seat cushion (G) also has Velcro. Align the Velcro to secure the seat cushion. After placing the long back cushion (E), use the tying straps to fix the back cushion to the sofa back panel.


Note: For a better appearance, the side with the zipper should generally face inward.



E × 1




G × 1



Step 1


As shown in the diagram, attach the two short coffee table side panels (J) to the long coffee table side panel (I), and tighten the bolts (S).
Note: Do not fully tighten the bolts.



I × 1	J × 2	S × 4 Bolt M6×35	General Tools

Step 2


Then align the holes on the other side of the short coffee table side panel (J) with the other long coffee table side panel (I), and fasten with bolts (S).
Note: Do not fully tighten the bolts.Pay attention to the direction of (J). The threaded holes of (J) should face inward, and the through holes of (I) and (J) should be on the same side.






I × 1	S × 4 Bolt M6×35	General Tools

Step 3


As shown in the diagram, fit the coffee table top (H) into the inner threaded side of (J), align the holes, and install with bolts (S).
Note: Do not fully tighten the bolts.






H × 1 	S × 4  Bolt M6×35	General Tools 

Step 4


As shown in the diagram, attach the long coffee table bottom frame (W1) to the bottom of the long coffee table side panel, and secure it with bolts (T) and nuts (O).
Note: Do not fully tighten the bolts.




 W1 × 2	T × 4  Bolt M6×50	O × 4 	General Tools 

Step 5

As shown in the diagram, use bolts (T) and nuts (O) to install the short coffee table bottom frame (W2) to the bottom of the short coffee table side panel (J), then secure the bottom frame with bolts (S).
Note: At this point, please check if all holes are aligned. If not, disassemble some parts and reinstall them. If all holes are aligned, tighten all screws.






W2 × 2

S × 4  Bolt M6×35


T × 4  Bolt M6×50


O × 4 

General Tools 


Step 6

Screw the 8 adjustable feet (P) into the 8 holes on the bottom frame and tighten them securely.



P × 8 

Assemble the sofa according to your preferences and secure it with the U-shaped clips to prevent the sofa from wobbling.



Sofa cover washing instruction and Maintenance and Care



Back pillow



Seat Cushion



Take the back insert out of the fabric cover



Take the cushion insert out of the fabric cover



Wash the cloth cover after removing it

Cleaning

For the rattan frame, use a damp cloth to clean off dust, dirt, or stains. Avoid using harsh chemicals, abrasive cleaners, or scrubbers.

For the cushions and pillows, follow the care instructions on the covers. Wash removable covers in cold water, and for non-removable covers, spot clean with mild soap and water.

Storage

If the sofa set is not in use for extended periods, cover the furniture or store it indoors in a dry, cool location to prevent damage from weather or dirt.

Inspection:

Regularly check the furniture for any loose parts, wear, or damage. Tighten screws and bolts as needed, and replace any damaged components promptly.

Scan the QR code to learn more about our product.