
## **ASSEMBLY INSTRUCTIONS**



## + Do Not Use Power Tools



# + Suggested Adults



### + Parts Included

1 Table Top(1PC)

2 Join Box(1PC)





3 Leg(4PCS)



#### **NOTE:**

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

#### 1 IMPORTANT SAFETY INFORMATION

**Do not** assemble the product if any of the following parts arrived damaged:

Part # (1) - Table Top

Part # (2) - Join Box

Part # (3) - Leg

**Do not** assemble if any of the following Hardware parts are missing:

Part # A - Bolt Part # B - Bolt

Part # C - Flat washer Part # D - Spring washer

Part# E - Spring Part# F - Adjustable washer footer

Part # G - Flat washer Part # H - Allen Key

## 2 IMPORTANT ASSEMBLY INFORMATION

**Assembly Step** If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

## + Hardware Included

A Bolt (4PCS)

B Bolt (8PCS)

8\*12mm

6\*16mm

C Flat Washer(8PCS)

**D** Spring Washer(4PCS)





6\*16mm

8\*12mm

**E**Spring Washer(8PCS) **F** Adjustable

F Adjustable (4PCS)



6\*10mm



**G** Flat Washer(4PCS)


H Allen Key(1PC)



8\*20mm




## **ASSEMBLY INSTRUCTIONS**




A. Position Table Leg (3) and Join box (2) as shown.

B.Use Screw (B) fitted with Flat Washer (C) & Spring Washer (E) to fasten the leg assembly to (2) & (3). Use Allen Key (H)to drive (B). Do not tighten.



- A.Lay Table Top (1) that does not scratch the part and position leg assembly from STEP 1 as shown.
- B.Align the bolt hole Rail to the respective bolt hole on the bottom of the top.
- C.Use Screw (A) fitted with Flat Washer (G) Spring Washer (D) to fasten the leg assembly to (1). Use Allen Key (H) to drive (A). Do not tighten.





The assembly of the table is complete. and adjustable balance.