








KEEP INSTRUCTIONS  
FOR FUTURE USE

ASSEMBLY REQUIRES  
TWO PEOPLE




## Assembly Instructions

Hardware and Tools		
A	Bolt	
	Qty: 4	
B	Washer	
	Qty:4	
C	Hex Key	
	Qty:1	
D	Ajustable pad	
	Qty:8	
E	Spring washer	
	QTY:4	


### Before Starting:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Always read the instructions carefully before beginning assembly to ensure that you have all required contents.
3. To prevent choking hazards, keep the packaging material out of reach of small children
4. Do not over tighten the bolts as this may damage the thread.
5. Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.
6. The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.

### Components:




Top




Leg


Step 1: Put the top as the picture and center the holes of the leg to the screw hole of the top.



Step 2: Insert the bolts through the spring washer and washer into the centered holes and turn until secure.



Step 3: Mount the adjustable pads (4) .



Step 4: Finish.

