




Retractable Hose Reel Set



V3.0 072024



vegogarden.com

Cautions

- The Retractable Hose Reel should only be installed outdoors.
- Use with cold water only.
- Do not use under the influence of medication, alcohol or drugs.
- Do not leave unattended around children or people with reduced capabilities.
- Exercise caution when installing. Bend your knees and not your back to avoid injuries.
- Avoid leaning on the hose reel to prevent potentially damaging the product.
- Mount your hose reel in a location away from direct sunlight to prevent overheating.
- When not in use, turn off the faucet and depressurize the hose.

Parts List

Retractable Hose Reel

Retractable Hose Reel x 1 Wall-Mounting Bracket x 1 Mounting screw with washer x 4 Wall Plug x 4

Nozzle

9-Pattern Spray Nozzle x 1 Adjustable Shot Nozzle x 1

Quick connect set

Tap Adapter A1 x 1 Male Thread Quick Connector C1 x 1 Tool-End Adapter A2 x 2 Female Thread Quick Connector C2 x 1

Tap End Tool End

Installation

Location

- Cement, brick or flat-wood wall
- Install at approximately waist height and up to 5 feet (1.5 meters) away from outdoor faucet

Tools Required

- Electric drill
- Hammer
- Masonry drill 7/16 inch or 11/64 inch bit
- Socket set, 3/8 inch (10mm)
- Eye and glove protection for safety



vegogarden.com

Step 1

7/16" or 11/64"

4"x4" Wood Block

- Use the Wall-Mounting Bracket to mark four positions, and drill four two-inch deep holes.

Step 2

- Hammer four wall plugs into the holes (not required for the wood block).
- Mount bracket on the wall or wood block with the washers and screws provided.

Step 3

180°

The hose reel can be padlocked to the bracket to protect against theft (padlock is optional and not included in this set).

- Position the reel and put the bottom post into the bracket hole. Test to make sure the hose reel is able to pivot 180 degrees.
- For Tool-End, attach the Tool-End Adapter (A2) to the nozzles. Attach the Female Thread Quick Connector (C2) to the short hose end from the reel.

Step 4

A1 C1

- For Tap-End, attach the Male Thread Quick Connector (C1) to the main hose via the Tap Adapter (A1) as shown.

Your Retractable Hose Reel is now ready to use.

How To Use

ON/OFF

MIST FLAT SOAKER
CONE RINSE SHOWER
VERTICAL ANGLE CENTER

PINPOINT SWEEP SPRAY

How To Use

- **To unwind:** Gently pull hose and lock at a desired length. Pull slightly harder to fully extend the hose.
- **To retract:** Release the lock by pulling the hose, while gently guiding it back to the reel.


At full extension, you may need to pull harder to retract. If the hose becomes jammed, gently pull out and retract it again.

⚠ WARNING

Do not retract the hose at high speed, as this may cause injury and damage the product.

Storage

Drain the hose completely and turn off the faucet during freezing temperatures.



vegogarden.com

Specifications

PRODUCT	HOSE LENGTH (FT)	HOSE DIAMETER (INCH)	HOSE MATERIAL	WORKING PRESSURE (PSI)	NET WEIGHT (LBS)
RETRACTABLE HOSE REEL SET - 130'	130	7/16	PVC	40-60	38.00
RETRACTABLE HOSE REEL SET - 100'	100	7/16	PVC	40-60	30.99
RETRACTABLE HOSE REEL SET - 65'	65	7/16	PVC	40-60	21.42
H-FLOW RETRACTABLE HOSE REEL SET - 100'	100	9/16	PVC	40-60	33.71
H-FLOW RETRACTABLE HOSE REEL SET - 82'	82	9/16	PVC	40-60	29.45
H-FLOW RETRACTABLE HOSE REEL SET - 50'	50	9/16	PVC	40-60	22.30

● MAX PRESSURE FOR HOSE REEL: 150PSI

Troubleshooting

Unable to retract or unwind:

- Turn off the faucet and pull the hose gradually.
- Open the nozzle and release excess pressure, and proceed to retract slowly.

If the problem persists, do not attempt to repair and disassemble the product yourself. Contact Vego Garden customer service for further assistance.

Leakage:

- Remove side panel with a flat screwdriver on the adjacent side of the main hose, and tighten the nut connecting the hose to the reel.

If the problem persists, contact Vego Garden customer service for further assistance.

Hose kinks:

- Pull the hose out and turn on the faucet. Allow water to flow and fully extend the hose. Retract the hose when the kink is resolved.

Hose replacement:


- If the hose is damaged, do not attempt to repair it yourself. Contact Vego Garden customer service for further assistance.

Warranty and Service

Your Retractable Hose Reel Set comes with a 24-month warranty from the date of its purchase.

Contact Us

- +1 (866) 597-1888
- vegogarden.com
- hello@vegogarden.com
- Vego Garden Academy
- vegogarden
- Houston, TX



vegogarden.com