
INSTALLATION INSTRUCTIONS

8'x10' Gazebo



Our team is available 24/7 to help with any product questions. Contact us anytime!

Warning

- Please read and understand this manual carefully before assembly. Before starting to assemble the product, please ensure that all parts are present. Please check the parts against the packing list. If you find any missing parts, please contact us.
- Any assembly or maintenance work on this product must be performed by adults. We recommend that at least two adults be involved.
- Please check your state and local regulations before purchasing. Some areas may require a permit for the installation and use of this product. There may be specific procedures in your area.
- Please install the Gazebo on a flat surface. Ground stakes are included with the product to secure the Gazebo to the ground.
- Do not assemble the Gazebo on sandy, muddy, or loose soil, as the ground stakes will not provide sufficient anchoring in these types of soil.
- If you wish to secure the Gazebo to a wooden deck or concrete surface, please use anchor bolts suitable for these surfaces.
- Some parts may contain sharp edges. Protective gloves are recommended.
- Keep children and pets away while assembling the Gazebo.
- Regularly check all nuts and bolts to ensure they are tightened.
- Before starting assembly, carefully read each step and ensure you understand each step.
- Please refer to the diagrams. Place all parts from the box in a clean area and lay them flat on the floor in front of you.
- Remove all packaging materials and place them back in the box. Do not discard the packaging materials until assembly is complete.

Maintenance

- Snow must be removed regularly during snowy weather. Remove snow when the snow accumulation on the roof exceeds 2 inches (5 cm). To avoid damage, use a plastic snow rake to remove excess snow and ice from the roof, and be careful to stay clear of falling debris.
- This Gazebo is for decorative and shading purposes only and is not designed to withstand severe weather conditions, including strong winds, heavy rain, and heavy snow.
- The steel components of this Gazebo are coated with rust-resistant paint. However, due to the inherent properties of steel, oxidation (rusting) may still occur on the surface if the protective coating is scratched. This is not a product defect and is therefore not covered under warranty.
- Please place the gazebo or heat source at a safe distance from wooden structures. Never allow open flames to come into direct contact with the wood panels. Due to the natural characteristics of wood, variations in grain, color, and texture are normal and do not affect the product’s performance. As the wood gradually acclimates to its environment, minor cracking, splitting, or fissures may occur. Such conditions are not covered by the warranty. To minimize cracking, we recommend regularly applying a wood preservative sealant and avoiding prolonged exposure to extreme humidity or direct heat sources.

Maintenance

- To minimize this occurrence, it is recommended to handle the product carefully during assembly and handling to avoid scratching the paint. If any scratches or damage occur, it is recommended to immediately repair the scratches with rust-resistant paint (not included).
- Do not use bleach, acid, or other abrasive cleaners on the roof or frame components.
- Please keep these instructions for future reference.


Matters needing attention



1.Two or more people are required for assembly.



2.Do not fully tighten screws prior to complete assembly.



3.Use a spirit level. Before proceeding, check that the device or component is perfectly level.




4.Use a square to check: Before tightening the bolts, check that the assembly is square.




5.Do not overtighten the mounting bolts. Overtightening can cause the wood to crack, splinter, and result in other structural damage.

INSTALLATION BLUEPRINT


8'x10'








PRODUCT DIMENSIONS

8'x10'















EXPLODED DRAWING















Part Lists(box 1)

Part Number	Part Image	QTY
30		1
31		1
33		2
17		1
18		1










Part Lists(box 2)

Part Number	Part Image	QTY
C5		3
R1		1
R2		1
R3		1
R4		1
R5		1
R6		1
R7		2






Part Lists(box 2)

Part Number	Part Image	QTY
D1		2
H1		2
E1		1
E2		1
Y1		4
32		2
34		1
20		2
21		1
22		1
23		1
24		1
27		1
26		1
11		1

Part Lists(box 2)

Part Number	Part Image	QTY
12		1
13		1
14		1
15		1
16		1
E3		2
H4	 M5x25	40+2
AA	 M4x16	108+6
BB	 M6x20	57+3
EE	M6x95	12+1
LL	 M8	16+2
H9	 M8	88+5
H7	 M8x150	16+1
CC	 M6x25	52+3
H8	 M6x30	24+2








Part Lists(box 2)

Part Number	Part Image	QTY
H5	 M6	28+3
FF	 M6x20	24+2
GG	 M6x15	128+6
KK		16+2
H6	 M6x55	7+1
DD	 M6	4+2
H2	 M6x65	6+1
H3	 M6x120	2+1
HH	 M6x35	6+1
E9	 M5x35	2+1
UU	 M6x80	10
PP	D8x180	10
Z1	 M8	2
Z2	 M6	2
Z3	 M6	2












Part Lists(box 2)

Part Number	Part Image	QTY
Z4	 M8	2
Z5		1




Part Lists(box 3)

Part Number	Part Image	QTY
C1		2
C2		1
C3		2
C4		1
K3		2
D2		2
L1		2
G3		9
E4		6
F1		2
F2		2


Part Lists(box 3)

Part Number	Part Image	QTY
M1		1
M2		2
T1		2
T2		2
G1		5
B5		1
B6		1
B7		2
D3		2
J1		2
J2		1
J3		1
G2		1
S		7
B		4

Part Lists(box 3)

Part Number	Part Image	QTY
C		4
B1		2
U1		1
G5		2

Part Lists(box 4)

Part Number	Part Image	QTY
Q1		16
K1		1
K2		1
K4		14

STEP 1


30 1PCS

B 1PCS

C 1PCS

H4 4PCS

M5x25



STEP 2


31 1PCS

B 1PCS


C 1PCS


H4 4PCS

M5x25





STEP 3


33
2PCS
32
2PCS
Y1
4PCS
B
2PCS
C
2PCS
AA
M4x16
24PCS
H4
M5x25
8PCS
BB
M6x20
4PCS
EE
M6x95
4PCS



32
Y1
Y1
33
B
C
32
AA
BB
EE
AA
33
B
H4
C


STEP 4



17
1PCS
18
1PCS
G1
1PCS
T1
2PCS
H9
8PCS
M8
BB
8PCS
M6x20
CC
8PCS
M6x25


T1
18
T1
17
G1
STEP 1
CC
CC
H9
BB
STEP 2
CC
H9
BB
x2
18
17

STEP 5


20
2PCS
G1
1PCS
T2
2PCS
H9
M8
12PCS
BB
M6x20
10PCS
CC
M6x25
10PCS


T2
20
T2
20
G1



STEP 1
CC
H9
BB
STEP 2
CC
H9
H9
T2
BB
x2
20
20

STEP 6

LL M8 4PCS

H9 M8 8PCS

H7 M8x150 4PCS




STEP 7


LL M8 4PCS


H9 M8 8PCS


H7 M8x150 4PCS




STEP 8



21
1PCS
22
1PCS
G1
1PCS
H9
4PCS
M8
BB
4PCS
M6x20
CC
4PCS
M6x25



22
G1
21


H9
CC
CC
BB
22
21

STEP 9


23
1PCS
24
1PCS
G1
1PCS
H9
4PCS
M8
BB
4PCS
M6x20
CC
4PCS
M6x25


23
24
G1



CC
CC
H9
BB
23
24

STEP 10


LL M8 8PCS

H9 M8 16PCS


H7 M8x150 8PCS



a x2




b x2





STEP 11


11	1PCS	12	1PCS	13	1PCS
14	1PCS	15	1PCS	16	1PCS
H8 M6x30	24PCS	H5 M6	24PCS		



STEP 12



27
1PCS
26
1PCS
G1
1PCS
H9
4PCS
M8
BB
4PCS
M6x20
CC
4PCS
M6x25


27
26
G1


CC
CC
H9
BB
27
26

STEP 13

G5	2PCS	H9	8PCS	BB	8PCS
			M8		M6x20
FF	8PCS				
	M6x20				




STEP 14

B7 2PCS


B5 1PCS


B6 1PCS

AA 8PCS
M4x16



STEP 15


D1
2PCS
D2
2PCS
D3
2PCS
GG
16PCS
M6x15


D2
D3
D1
GG
D1
GG
D2
D3
D1
GG
D2
GG
D2
D1


STEP 16

H9 4PCS M8


BB 4PCS M6x20

CC 4PCS M6x25


GG 8PCS M6x15




a



b





c



STEP 17

C1 — 2PCS	C2 — 1PCS	GG — 16PCS (M6x15)
C3 — 2PCS	C4 — 1PCS	AA — 4PCS (M4x16)







STEP 18


C5 3PCS

AA M4x16 12PCS

Pay attention to the fold direction when installing







STEP 19


Q1 16PCS

S 7PCS

KK 16PCS


FF 16PCS
M6x20

AA 32PCS
M4x16




STEP 20

R1	1PCS	R2	1PCS
R3	1PCS	R4	1PCS
AA	16PCS M4x16		





STEP 21

R5	1PCS	R7	2PCS
R6	1PCS	AA	12PCS M4x16




STEP 22







a x2



b




c




STEP 23


H1 2PCS

H4 12PCS
M5x25







STEP 24









STEP 25








STEP 26




X7






STEP 27

GG 8PCS
M6x15



a x4


Loosely screw in the screws first



STEP 28


GG 28PCS

M6x15



ax14

Loosely screw in the screws first




STEP 29

L1 2PCS

CC 18PCS
M6x25

H4 2PCS
M5x25




STEP 30

F1 2PCS

DD 2PCS
M6

H5 2PCS
M6

H6 2PCS
M6x55



STEP 31

F2 2PCS


G2 1PCS

GG 4PCS M6x15

DD 2PCS M6

H5 2PCS M6


H6 2PCS M6x55




STEP 32

GG 8PCS
M6x15


Pay attention to the direction of the countertop face




a x2




b




c




STEP 33



34
1PCS
B1
2PCS
H4
4PCS
M5x25
BB
3PCS
M6x20
H9
2PCS
M8
H6
3PCS
M6x55


BB
H9
H6


a



34
H4
BB
H6
B1
H4


b


a
34
b

STEP 34









STEP 35

E4 6PCS

H2 6PCS
M6x65



a x 6




STEP 36

E3 2PCS


H4 4PCS
M5x25

H9 2PCS
M8


H3 2PCS
M6x120



a x2



b




STEP 37

M2 2PCS

M1 1PCS


E9 2PCS
M5x35

Please fix the m2 according to the size of the TV.



STEP 38

GG 4PCS
M6x15





STEP 39

U1 1PCS

HH 6PCS
M6x35

H4 2PCS
M5x25





STEP 40

UU 10PCS
M6x80

PP 10PCS
D8x180

