

FIXING YOUR DIMMER SWITCH

If your Metal Dimmer Switch turns without dimming
Here are 4 easy steps to follow

STEP 1: Locate the small hex nut on the side of your metal dimmer switch cover.



STEP 2: Insert a 0.2mm Allen wrench and tighten until snug. Do not overtighten.



STEP 3: Turn Dimmer Switch Cover to Ensure It Is “CATCHING”



STEP 4: Dim up and dim down and set the right mood in your environment.

