


CHAISE LOUNGE












Read the instructions before use of this product.

Please keep this instruction manual for future reference.





PARTS & HARDWARE LIST






PART	FIGURE	DESCRIPTION	QTY
A		Right Arm	1x2
B		Left Arm	1x2
C		Seat Panel	1x2
D		Back Panel	1x2
E		Bolt M6*55	2x2
F		Bolt M6*20	8x2
G		Washer	10x2
H		Plastic Washer	2x2
I		Nut	2x2



PARTS & HARDWARE LIST

PART	FIGURE	DESCRIPTION	QTY
J		Allen Key	1
K		Wrench	1

EXTRA

PART	FIGURE	DESCRIPTION	QTY
E		Bolt M6*55	1
F		Bolt M6*20	2
G		Washer	3
H		Plastic Washer	1
I		Nut	1

ATTENTION:

Keep children away during assembly. This item contains small parts that can be dangerous for children. Children should always be under direct adult supervision while using this product.

Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.


Carefully remove the contents from the package. If any parts are missing, do not attempt to use the product until they have been obtained.

Make sure that each bolt needed for all steps matches the corresponding figure to ensure proper assembly.




STEP 1

Place the seat panel (C) onto a non-abrasive surface, such as carpet.
And open the seat panel (C).



STEP 2

Attach the right arm(A)and left arm (B) to seat panel(C) using bolts M6*20(F)
and washers(G).
Please do not fully tighten bolts until is fully assembled.




Tip: Please screw the upper bolts firstly.



STEP 3

Attach back panel (D) to seat panel (C) using bolts M6*55(E), washers(G), plastic washer(H) and nuts(I).

Please fully tighten all bolts using allen key (J) and wrench (K) .



Cleaning and Maintenance

Clean frame with mild soapy water, rinse thoroughly. Dry frame parts completely. Do not use bleach, acid, or other solvents on the fabric and metal parts.

We recommend the use of furniture covers to protect the Chaise Lounge when not in use.

Inspect and tighten all bolts on a regular basis to ensure proper performance and safety.

In order to prolong the life and beauty of your Chaise Lounge, we recommend storing it in a dry and protective area during off season periods.