




Portable Spike Light

SKU: HGSL15A

[Instruction Manual]



Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

CAUTION RISK OF FIRE

USE 150 WATT OR SMALLER 120 VOLT, TYPE PAR38 BULB

Use care when plugging in or handling lamp or cord as you would with any outdoor electrical equipment. When installing or replacing floodlight be sure gasket is properly in place for a safe weatherproof installation.

CAUTION: IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a **POLARIZED** plug (one blade is wider than the other). As a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature.

WARNING :

When using outdoor use products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following.

READ ALL INSTRUCTIONS

- a) Ground Fault Circuit Interrupter (GFCI) protection is to be provided on the circuit(s) or outlet(s) to be used for the wet location portable luminaire. Receptacles are available having outlet(s) to be used for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety.
- b) Use only with an extension cord for outdoor use, such as an extension cord of cord type SEW, SEOW, SEOOW, SOW, SOOW, STW, STOW, STOOW, SJEW, SJEOW, SJEOOW, SJW, SJOW, SJOOW, SJTW, SJTOW, or SJTOOW.


SAVE THESE INSTRUCTIONS

FLOODLIGHT SOCKET AND MOUNTING HARDWARE

High-impact fixture resists weather and wear. Optional spike for lawn use. Use Par 38 floodlight only. Max 150 watts/120 volts.

1. Optional A: Attached assembled floodlight securing the wing nut to wall, floor or ceiling with screw or nail using holes in plate.
2. Optional B: To use on lamp, screw the stake with round plate, fully insert stake only up to indicator line. Set light to proper angle, direction and securely tighten with wing nut.
3. Plug into outlet or electrical extension cord.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov



Specifications

- Model: GL-015
- Input voltage: 120VAC 60Hz
- Wattage Max. : 150W

Packing List

- Portable Spike Light x2
- Instruction Manual x1

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation.

Please attach your Order ID and Name so that our dedicated customer service team can help you better.



Made in China