Assembly Instructions


CAUTION: You must read this before you proceed.


Please look in the Seat Panel for hardware packs.

ARMLESS CHAIR



Parts List					
No.	Picture	Description	Qty		
А		Backrest Panel	1		
В		Left Arm Panel (With Pre- installed Levellers)	1		
С		Right Arm Panel (With Pre-installed Levellers)	1		
D		Seat Panel	1		
Е		Support Bar	1		
F		Seat Cushion	1		
G		Back Cushion	1		
Hardwa	Hardware				
No.	Picture	Description	Qty		
1		Bolt (M6x35mm)	7		
2		Screw (M6x45mm)	5		
3		Allen Key	1		





Place the Right Arm Panel (C) with inside face skywards onto a clean, soft surface to avoid any scratches or damages to the product.


Step 2.1: Align the dowels of Support Bar (E) into the positions in the Right Arm Panel (C) as shown above.

Then, affix Support Bar (E) with Right Arm Panel (C) by using Bolt (1) and Allen Key (3).

Step 2.2: Attach the Backrest Panel (A) onto Right Arm Panel (C) by using Bolts (1) and Allen Key (3).

DO NOT FULLY TIGHTHEN BOLTS.

Step 3




With the help of your adult partner, place Left Arm Panel (B) onto the assembled in Step 2 as shown above

Step 3.1: Align the dowels of Support Bar (E) into the positions in the Left Arm Panel (B).

Then, affix Support Bar (E) with Left Arm Panel (B) by using Bolt (1) and Allen Key (3) as shown above.


Step 3.2: Pre-attach the Left Arm Panel (B) onto Backrest Panel (A) by using Bolts (1) and Allen Key (3) as shown above.


DO NOT FULLY TIGHTHEN BOLTS.




With the help of your adult partner, place the assembled in Step 3 right side up as shown above.

By hand, hold Left Arm Panel (B) and Backrest Panel (A) together tightly then secure the Left Arm Panel (B) and Backrest Panel (A) by using Bolts (1) and Allen Key (3) as shown above.







With assistance from your adult partners, up side down the chairs and using pre-fixed clip to connect the chairs together

Ca	re &	Maintenance	
\otimes	<u></u>	• Do not put hot items directly on furniture surface	
\otimes		 Do not clean furniture with harsh cleansers or polish. 	
~	Ö	• To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to d sunlight is recommended.	lirect
0	×	• Children should not climb or jump on the furniture.	
0	P	• Do not write on furniture without a padded barrier to protect the surface.	
~	<u></u>	• To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.	
\odot		 Not for commercial use. For residential use only . 	
0	6 H 140	• Stains may be removed with mild soap solution and damp cloth.	
~		Dust and pick-up spills using a clean, non-colored, lint-free cloth .	