




STORAGE CABINET

User Manual


INTRODUCTION

Thank you for choosing the Storage Cabinet. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact us by email with your order number and details.

PACKAGE CONTENTS


- 1 x Storage Cabinet
- 1 x Pack of Accessories
- 1 x User Manual

PANEL LAYOUT




PARTS LIST → **(A)** BOX

(5) 79.9*50.7*1.5 cm




x1

(9) 76.8*7*1.5cm




x1

(11) 76.1*22.7*1.5 cm




x3

(12) 71.9*14.5*1.2 cm




x3

(14) 33.7*5*1.2cm




x3

(15) 35*14.5*1.2cm




x3

(16) 35*14.5*1.2cm




x3

(17) 76.8*7*1.5cm



x1


(18) 76.8*7*1.5cm



x1


PARTS LIST → **(B)** BOX

(1) 99.9*50.6*1.5cm



x1


(2) 99.9*50.6*1.5cm



x1


PARTS LIST → **B** BOX

③ 78.4*50.6*1.5 cm




x1

④ 78.4*50.6*1.5 cm




x1

⑥ 76.8*50.5*1.5 cm




x1

⑦ 76.8*7*1.5 cm




x2

⑧ 76.8*48.9*1.5 cm




x1

⑩ 76.2*3*1.5 cm




x1

⑬ 34.6*72.7*0.3cm




x3

⑰ 76.8*7*1.5cm




x1

⑳ 76.8*7*1.5cm




x1

㉑ 77.6*46.5*0.3cm




x2

㉒ 77.6*34.2*0.3cm













x2

㉓ 99.4*38*1.5cm



x2

ACCESSORIES LIST → (B) BOX

			TOOLS REQUIRED:		
A 6*35 mm  x47+3	B 15*10 mm  x47+3	C 5.8*30 mm  x28+3	Screwdriver 	Hammer 	
D 4*35 mm  x17+2	E  x4	F 3*16 mm  x18+2	G 4*14 mm  x24+2	H  x2	
I 3.5*12 mm  x36+3	J 4*14 mm  x2	K 4*16 mm  x8	L  x2	M  x16	
N  x1	O  x2	P 6*25 mm  x4	(CL)  14 in x3	(DL)  x3	
(DR)  x3	(CR)  x3	Q  x1	R  x4	S 5.8*50mm  x4	T 3.5*14mm  x4

PRODUCT CARE

- Please follow the instruction to assemble this item correctly.
- Don't make the screws be too loose or too tight.
- Please put the screws into the holes' position just as shown in the arrows of the image, and then clockwise rotate 90° or 180°
- More product parts, it is recommended that two people install
- The fittings pack contains small accessories that should be kept away from small children.

1

YOU WILL NEED



I x9

CL x3

A x8

R x2

CL



2

YOU WILL NEED



I x9

CR x3

A x8

R x2


CR



3

YOU WILL NEED

A x4




4

YOU WILL NEED

C x4

B x4




5


YOU WILL NEED

C x8

B x8



6






7

YOU WILL NEED

B x8

C x8






8

YOU WILL NEED

A x8

H x2

T x4




9


YOU WILL NEED

B x4

C x2



10






11


YOU WILL NEED

B x4

C x2



12



13

YOU WILL NEED


A x4

B x4

C x4

F x2

N x1



14


YOU WILL NEED

S x4

P x4

Q x1


NOTE: This step ti be accomplished by two persons



S x4

P x4

Q



15



YOU WILL NEED

F x16

M x16


O x2

J x2



F x16


M x16



16

YOU WILL NEED

D x15



x3


17

YOU WILL NEED

A x15

B x15

K x6



x3

18


YOU WILL NEED

I x18




DL x3

DR x3

DR



DL



x3


19

YOU WILL NEED



E x8

G x4

K x2



x4






x2

20

YOU WILL NEED


G x16




The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.



Components Name



Obvious gap between doors or Doors don't look closed



- 1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

- 1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.


- 2 Push the door to the cabinet




- 3 Rotate the "front and rear screws" to the right




When door is leaning




- 1 Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the upside




- 1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




- 1 Turn "up & down screw" to the left



- 2 Lower the door's height so that 2 doors are of the same height.



- 3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2


21

YOU WILL NEED

D x2

O x2

L x2



! WARNING




**Children have died from furniture tipover.
To reduce the risk of furniture tipover:**

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



This is a permanent label.

Do not remove!



GUARANTEE

Bookcase offers a **90-days** warranty that begins on the date of the original purchase and applies to problems caused by the manufacturer. For questions, assistance, or support, please contact the Customer Service by e-mail with your order number and details. We will send you further information about the solution.

MODEL: YG-106

Made in China

