

TULIP-LQ




Ax1		Fx1	 M6x45MM
Bx1		Gx4	 M6x55MM
Cx1		Hx5	
Dx1		Ix1	
Ex2	 M6x35MM	Jx4	


SPARE (Ersatzteile)

Ex1	 M6x35MM	Hx1	
Gx1	 M6x55MM	Jx1	


STEP 1



STEP 3



STEP 2



STEP 4

