





89338/89339


SOFA BED WITH USB & MAGAZINE POCKET






1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **FOR INDOOR RESIDENTIAL USE ONLY.**


PARTS




(A) Seat body (1pc)




(B) Pull - out frame (1pc)



(C) Left Armrest (1pc)



(D) Right Armrest (1pc)




(E) Pillow (2pcs)



(F) Wooden Legs (4pcs)




(G) Platic Washer (4pcs)



(H) Wheel (4pcs)

HARDWARE LIST




(1) Bolts 1/4*1" (8pcs)



(2) Spring Washer (8pcs)





(3) Flat Washer (8pcs)




(4) Allen key (1pc)


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7.1



STEP 7.2



STEP 7.3



STEP 7.4

