


Assembly Instructions



warning notice



- Open your item in the area you plan to keep it for less heavy lifting.



- Identify, sort, and count the parts before attempting assembly.



- Lay all parts on smooth flat surface.



- Make sure to always face the point on the top of the Cam Lock towards the outer edge.




- Do NOT use harsh chemicals or abrasive cleaners on this item.



- Never push, pull, or drag your furniture.

Teamwork



Failure to use 2 people for assembly could result in unit damage or personal injury.

Before You Start


Read through each step carefully and follow the proper order

Separate and count all your parts and hardware

Give yourself enough room for the assembly process




Have the following tools: Phillips Head Screwdriver and Hammer

Caution: If using a power drill or power screwdriver for screwing please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.




If the door panel is not sitting at a right position or angle, follow the steps below to improve.











- (1) Loosen the hinge, adjust the door panel position (up and down) then fasten the screws to secure the hinge (Step 1), or,
- (2) Loosen the middle screw of the hinge and adjust the door panel in and out, to desired position, then fasten the screws to secure the hinge (Step 2), or
- (3) Adjust the nut at the centre of the hinge to fine tune the tilting angle of the door panel (left or right) to make the door panel to be vertical.














Components



Components



A  M6x35mm 34PCS	B  Ø15x9mm 34PCS	C  M4x40mm 14PCS	D  Ø6x30mm 36PCS
E  8PCS	F  Ø6x50mm 3PCS	G  M4x12mm 78PCS	H  8PCS
I  M6x20mm 8PCS	J  M4mm 1PC	K  2PCS	L  1PC
M  1PC	N  1PC	O  1PC	

Components




Assembly Instructions

1



A x 12PCS


2



B x 12PCS




D x 8PCS




Assembly Instructions

3



F x 3PCS

4






C x 14PCS



D x 12PCS




Assembly Instructions

5



A x 14PCS


6




A x 4PCS

Assembly Instructions


7




	B x 4PCS
	D x 4PCS



8




	B x 14PCS
	D x 12PCS





Assembly Instructions

9



E x 8PCS




10



A x 4PCS

Assembly Instructions

11





I x 8PCS




J x 1PC

12




B x 4PCS




Assembly Instructions

13



	G x 32PCS
	H x 8PCS


14



	G x 10PCS
	K x 2PCS



Assembly Instructions

15



	G x 8PCS
	L x 1PC
	M x 1PC


16



	G x 12PCS
	N x 1PC
	O x 1PC

Assembly Instructions

17



G x 16PCS