





Assembly Instruction




A: left arm x1pcs




B: right arm x1pcs



C: back arm x1pcs




D: seat cushion x1pcs




E: backrest x1pcs


Step 1. Install the seat cushion(D) on left arm(A) & right arm(B) first; finally install the seat cushion(D) on back arm(C) as follow.



Step 2. Push both side of backrest as follow.



Step 3. Install the backrest on left arm(A),back arm(C),right arm(B) as follow.



Finish

