



ASSEMBLY INSTRUCTIONS




WARNING !




MAXIMUM LOAD
220 lb/ 100kg



MAXIMUM LOAD
15.4 lb/ 7kg



Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.

PACKAGE CONTENT


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




① x1




② x1




③ x1




④ x1




⑤ x1




⑥ x2




⑦ x1




⑧ x1




⑨ x6




⑩ x6




⑪ x1




⑫ x1




⑬ x1




⑭ x1




⑮ x6



⑯ x6












⑰ x6




⑱ x6

HARDWARE LIST


 Ø6x33.5mm A x50+5	 Ø15x9.5mm B x50+5	 Ø6x30mm C x38+3	 Ø5x38mm D x10+1
 Ø3.5x12mm E x69+6	 F x12	 Ø6x12mm G x24+2	 Ø3x15 H x4+1
 5/32x10mm I x12	 J x5	 K x6 SET	 Ø4x38mm L x30+3
M1x2 140*19mm 	M2x4 Ø16xØ6.5x1mm 	M3x2 Ø4x16mm 	N1x2 Ø6x30 
			N2x2 Ø4x35 
M			N x1
 CL x6	 CR x6	 DR x6	 DL x6

Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.







STEP 1







STEP 2






STEP 3







STEP 4




STEP 5







STEP 6






STEP 7




CAUTION: Heavy! You may need assistance with this step



STEP 8






STEP 9




	
Ø6x30mm	Ø15x9.5mm
C x 3	B x 3

STEP 10




	
Ø6x30mm	Ø5x38mm
C x 6	D x 10





STEP 11







STEP 12





STEP 13




STEP 14




STEP 15




STEP 16






After this step is assembled,
flip it 180 degrees(to next step)




STEP 17




STEP 18




STEP 19




STEP 20






STEP 21







STEP 22







STEP 23




STEP 24




STEP 25



STEP 26




Cabinet Slide arms




Drawer Slide brackets



STEP 27





STEP 28



STEP 29



STEP 30



FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly
- Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

- Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
- Small amount of mild soap can be used if necessary
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF and PB.

Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.

Make sure to dry the furniture immediately after cleaning