
Patio Dining Chair

Instruction Manual



ASSEMBLY INSTRUCTIONS:

·Our detailed, easy-to-understand, step-by-step instructions will guide you through the entire assembly process.

·Follow each step without skipping. It is crucial to assemble all parts exactly as directed.

·Item identification: For simplicity, all parts are labeled to match the step number where they are used.

·Do not screw the screws tightly before finishing.

IMPORTANT:

·Carefully read the following instructions before using the chair.

·Be mindful that some parts are heavy and have sharp edges.

·Do not overtighten screws (Insert all screws before tightening them).

·Ensure all bolts, screws, and nuts are securely fastened before use.

·Do not exceed the weight limits of this item.

·Recheck that all bolts, screws, and nuts are secure every 90 days.

CARE & SAFETY:

·Always place on firm, level ground.

·Keep children and pets away from the assembly area. Supervise them while the product is being assembled.




·Ensure the assembled product is at least 6 feet (2 meters) away from any obstructions like fences, garages, houses, overhanging branches, laundry lines, or electrical wires.





·Do not use or store this item near open flames or flammable/combustible chemicals.


·In case of fire, do not attempt to extinguish any burning polypropylene with water.





·Contact Customer Service **MUCH_Service@outlook.com** if you encounter any problems or discover any missing parts.


Assembly Parts

Item No.	Reference Image	Qty
A		X 1
B		X 1
C		X 1
D		X 1


Item No.	Reference Image	Qty
E		X 2
F		X 2
G		X 2
H		X 2




Item No.	Reference Image	Qty
1	 M6x50	x4
2	 M6x65	x10
3	 M6x75	x8
4	 M6x85	x2


Item No.	Reference Image	Qty
5	 M6 NUT	x10
6	 WRENCH	x1
7	 ALLEN WRENCH	x1






1


E x2
F x2
G x2
3 x4
7 x1


F
E
3
G
F
E
3
7
3
G
3


2


B x1
2 x4
5 x4
6 x1
7 x1


7
2
2
F
E
5
6
5
B


3






4






5

C x1 D x1 3 x4 7 x1




6

A x1 2 x2 4 x2 5 x2 6 x1 7 x1



INSTALLATION COMPLETED



PAY ATTENTION
DO NOT EXCEED THE MAXIMUM LOAD OF 330LBS

THANK YOU FOR SHOPPING WITH US!

If you have any questions, or need assistance with use, parts, or customer service, please contact: **MUCH_Service@outlook.com** .
To help us identify your order, please include your order number.
Our professional team will be there to assist you.

Customer Service Team

WARRANTY

Our Brand offers a 2-year basic warranty on the entire chair
defects in material and workmanship. During this period **Our Brand** will repair and replace, at our discretion, the defective component.

This warranty does not apply to improperly installed, handled, abused, damaged by user error, nor to any unit which has been repaired or altered by unauthorized repair companies.

Under no circumstances will the customer entitled warranty to consequential or incidental damages. This limited 2-year basic warranty will only grant customers certain legal rights, customers may have other rights according to different state laws.