
ASSEMBLY INSTRUCTION

DINING CHAIR



X3

N711P450349


IMPORTANT NOTE:

1: PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.








2: BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.

3: DO NOT TIGHTEN ALL SCREWS AND BOLTS UNITIL THE CHAIR IS FULLY SET - UP.


Detail View



Part List In Box

7 	8 	9 
BACK FRAME (3 pc)	SEAT FRAME (3 pc)	SUPPORT - LEFT (3 pc)
10 	11 	12 
SUPPORT - RIGHT (3 pc)	FRONT LEG - LEFT (3 pc)	SUPPORT- FRONT (3 pc)
13 		
FRONT LEG - RIGHT (3 pc)		

Hardware List In Box


F  1/4"x75 mm	G  1/4"x50 mm	H  1/4"x35 mm
BOLT (12 pcs)	BOLT (12 pcs)	BOLT (6 pcs)
I  1/4"x11 mm	J  1/4"x19 mm	E  4x58mm
LOCK WASHER (30 pcs)	FLAT WASHER (30 pcs)	ALLEN KEY (2 pc)
K  4x40 mm		
PAN HEAD SCREW (18 pcs)		

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




STEP 1:

H	I	J
6 pcs	6 pcs	6 pcs




STEP 2:

F	I	J
12 pcs	12 pcs	12 pcs




X3




STEP 3:

X3



STEP 4:

G	I	J	K
12 pcs	12 pcs	12 pcs	18 pcs



COMPLETE

